


DENSO injector Testing of the 502

It is a able testing of the one Denso injector only.


Step 1.

Must stop a hole of Rail Cap by Rail



Step 2.

Mounting the Denso injector




Step 3.

Signal cable connect to injector



to Bosch



Step 4. Testing for mode (LOW/middle/High)

