



Bom List

part code	description	qty	part code	description	qty
20HC85_001	oil extraction probe	1	20HC85_029	omni-directional wheel	2
20HC85_002	oil extraction probe	1	20HC85_030	square bend	1
20HC85_003	oil extraction probe	1	20HC85_031	butterfly ball valve	1
20HC85_004	oil extraction probe	1	20HC85_032	square quick coupling	2
20HC85_005	oil extraction probe	1	20HC85_033	hexagonal cover	2
20HC85_006	oil extraction probe	1	20HC85_034	transparent hose	1
20HC85_007	probe sleeve	1	20HC85_035	hex socket head screw	4
20HC85_008	inside metal strainer	1	20HC85_036	safety valve	1
20HC85_009	tray	1	20HC85_037	steering connection	1
20HC85_010	butterfly ball valve	1	20HC85_038	T-union (in. teeth)	1
20HC85_011	oil extraction hook	1	20HC85_039	wind nozzle	2
20HC85_012	lift pole	1	20HC85_040	pressure gage	1
20HC85_013	handle	1	20HC85_041	gasket	1
20HC85_014	mini valve	1	20HC85_042	steering connection	1
20HC85_015	drip-proof oil box	1	20HC85_043	mini-ball valve	1
20HC85_016	oil extraction tube	1	20HC85_044	right protective box	1
20HC85_017	hex socket head screw	1	20HC85_045	steering connection	1
20HC85_018	Inside and outside steering bend	1	20HC85_046	hexagonal nut	2
20HC85_019	o-ring	2	20HC85_047	meson	2
20HC85_020	plum knob	1	20HC85_048	hex socket head screw	2
20HC85_021	lift cover	1	20HC85_049	ejection hose parts	1
20HC85_022	o-ring	1	20HC85_050	vacuum generator	1
20HC85_023	liquid tank	1	20HC85_051	o-ring	1
20HC85_024	decorated nut	2	20HC85_052	screw	1
20HC85_025	meson	2	20HC85_053	screw	4
20HC85_026	directional wheel	2	20HC85_054	left protective box	1
20HC85_027	snap rings	2	20HC85_055	o-ring	2
20HC85_028	hexagonal screw	2			