

ISUZU

1. X : means the function is supported.

2. * : means the function is added or developed newly in the new version

VEHICLE INFORMATION				FUNCTION					
Region	Series&Year	System	Model	ECU INFO	DTC	DTC Freeze	Data List	Actual actions	Spec. Func.
ISUZU series	N Series Truck	Engine	4HK1-TC(C/Rail)	X	X		X		
ISUZU series	N Series Truck	Engine	4JJ1-TC(C/Rail)	X	X		X		
ISUZU series	N Series Truck	Engine	4JH1/4KH1	X	X		X		
ISUZU series	N Series Truck	Engine	4HK1-TC <C/Rail NLT>	X	X		X		
ISUZU series	N Series Truck	Engine	4HK1/4JJ1 <C/Rail Euro2>	X	X		X		
ISUZU series	N Series Truck	Engine	4HK1/4JJ1 <C/Rail Euro3>	X	X		X		
ISUZU series	N Series Truck	Engine	4HV1 CNG	X	X		X		
ISUZU series	N Series Truck	Engine	4JH1-TC Bosch 2008	X	X		X		
ISUZU series	N Series Truck	Engine	4JJ1-TC C, Rail NLT	X	X		X		
ISUZU series	N Series Truck	Engine	Idle stop BCM	X	X		X		
ISUZU series	N Series Truck	Engine	Hybrid system	X	X		X		
ISUZU series	N Series Truck	Engine	4HL1/4HJ1	X	X		X		
ISUZU series	N Series Truck	Engine	4IG2<LPG>	X	X		X		
ISUZU series	N Series Truck	Engine	4IG2	X	X		X		
ISUZU series	N Series Truck	Engine	4HG1<LPG>	X	X		X		
ISUZU series	N Series Truck	Engine	Denso 4HG1 (ECD-V4)	X	X		X		
ISUZU series	N Series Truck	Engine	MIMAMORI	X	X		X		
ISUZU series	N Series Truck	Engine	4HF1<CNG>	X	X		X		
ISUZU series	N Series Truck	Engine	4HL1/4HJ1 (Vehicle Interface Module)	X	X		X		
ISUZU series	N Series Truck	Body	Immobiliser	X	X		X		
ISUZU series	N Series Truck	Body	SRS	X	X		X		
ISUZU series	N Series Truck	Body	Body control module	X	X		X		
ISUZU series	N Series Truck	Body	Driving Safety Reference	X	X		X		
ISUZU series	N Series Truck	Transmission	AT A460	X	X		X		
ISUZU series	N Series Truck	Transmission	Smoother / Smoother-Ex	X	X		X		
ISUZU series	N Series Truck	Transmission	Smoother /Smoother-Fx	X	X		X		
ISUZU series	N Series Truck	Transmission	Smoother-E	X	X		X		
ISUZU series	N Series Truck	Transmission	Smoother/Smoother-E Auto Shift	X	X		X		
ISUZU series	N Series Truck	Chassis	ABS/ASR	X	X		X		
ISUZU series	N Series Truck	Information System	MIMAMORI	X	X		X		
ISUZU series	F&G Series Truck	Engine F	4HK1 TC C Rail F	X	X		X		
ISUZU series	F&G Series Truck	Engine F	6HK1-TC(C/Rail)	X	X		X		
ISUZU series	F&G Series Truck	Engine F	6HK1-TC	X	X		X		
ISUZU series	F&G Series Truck	Engine F	6HK1 TC(Europe V)	X	X		X		
ISUZU series	F&G Series Truck	Engine F	6HK1 TC C Rail 2	X	X		X		
ISUZU series	F&G Series Truck	Engine F	4HK1-TC <C/Rail NLT>	X	X		X		
ISUZU series	F&G Series Truck	Engine F	4HK1/6HK1 <C/Rail Euro2>	X	X		X		
ISUZU series	F&G Series Truck	Engine F	4HK1/6HK1 <C/Rail Euro3>	X	X		X		
ISUZU series	F&G Series Truck	Engine F	Idle stop BCM	X	X		X		
ISUZU series	F&G Series Truck	Engine F	6UZ1-TC <C/Rail Euro3>	X	X		X		
ISUZU series	F&G Series Truck	Engine F	6HK1-TC <C/Rail NLT>	X	X		X		
ISUZU series	F&G Series Truck	Engine F	6UZ1-TC (Common rail) engine	X	X		X		
ISUZU series	F&G Series Truck	Engine F	6UZ1-TC (Common rail)	X	X		X		
ISUZU series	F&G Series Truck	Body	Immobiliser	X	X		X		
ISUZU series	F&G Series Truck	Body	SRS	X	X		X		
ISUZU series	F&G Series Truck	Body	Body control module	X	X		X		
ISUZU series	F&G Series Truck	Transmission	Automatic Transmission	X	X		X		
ISUZU series	F&G Series Truck	Information System	Speedometer Control Equipment	X	X		X		
ISUZU series	F&G Series Truck	Information System	MIMAMORI	X	X		X		
ISUZU series	C&E Series Truck	Engine	6WG1-TC(C/Rail)	X	X		X		
ISUZU series	C&E Series Truck	Engine	6WG1-TC2 (Common rail)	X	X		X		
ISUZU series	C&E Series Truck	Engine	6UZ1-TC <C/Rail NLT>	X	X		X		
ISUZU series	C&E Series Truck	Body	Driving Safety Reference	X	X		X		
ISUZU series	C&E Series Truck	Chassis	Air Suspension	X	X		X		
ISUZU series	C&E Series Truck	Chassis	Millimeter Wavelength Radar Cruise	X	X		X		
ISUZU series	C&E Series Truck	Chassis	Hydraulic pressure retarder	X	X		X		
ISUZU series	C&E Series Truck	Information System	MIMAMORI	X	X		X		
ISUZU series	LT/LV Series Bus	Engine	6HK1-TC(C/Rail)	X	X		X		
ISUZU series	LT/LV Series Bus	Engine	6UZ1-TC <C/Rail Euro3>	X	X		X		
ISUZU series	LT/LV Series Bus	Engine	6HK1-TC <C/Rail Euro3>	X	X		X		
ISUZU series	LT/LV Series Bus	Transmission	Automatic Transmission	X	X		X		
ISUZU series	(C*, E*, L*, F*)Heavy-Medium Duty	Engine	6WF1-TC(C/Rail)	X	X		X		
ISUZU series	(C*, E*, L*, F*)Heavy-Medium Duty	Chassis	ESC(with EBS)	X	X		X		
ISUZU series	(C*, E*, L*, F*)Heavy-Medium Duty	Chassis	ABS 6	X	X		X		
ISUZU series	(C*, E*, L*, F*)Heavy-Medium Duty	Chassis	ABS/ASR ADVICS	X	X		X		
ISUZU series	(C*, E*, L*, F*)Heavy-Medium Duty	Chassis	ABS/ASR	X	X		X		
ISUZU series	(C*, E*, L*, F*)Heavy-Medium Duty	Transmission	AT Allison Lct	X	X		X		
ISUZU series	KV/KR Bus Series	Chassis	ABS 6	X	X		X		
ISUZU series	Off-Road Industrial Engine	Engine	4JJ1-TC <C/Rail Tier3>	X	X		X		
ISUZU series	Off-Road Industrial Engine	Engine	4HK1-TC <C/Rail Tier3>	X	X		X		
ISUZU series	Off-Road Industrial Engine	Engine	6HK1-TC <C/Rail Tier3>	X	X		X		
ISUZU series	Off-Road Industrial Engine	Engine	6UZ1-TC <C/Rail Tier3>	X	X		X		
ISUZU series	Off-Road Industrial Engine	Engine	6WG1-TC <C/Rail Tier3>	X	X		X		
QingLing ISUZU series	Engine System	Euro IV		X	X		X		
QingLing ISUZU series	Engine System	6HK1-TC		X	X		X		

Region	Series&Year	System	Model	ECU INFO	DTC	DTC Freeze	Data List	Actualions	Spec. Func.
Qingling ISUZU series	Engine System	6HK1-TC(as of 2007)		X	X		X		
Qingling ISUZU series	Engine System	6HL1		X	X		X		
Qingling ISUZU series	Engine System	6UZ1 Engine(Euro 5)		X	X		X		
Qingling ISUZU series	Engine System	6W*1-TC<C/Rail DLT 3pin>		X	X		X		
Qingling ISUZU series	Engine System	6WF1-TC Engine System		X	X		X		
Qingling ISUZU series	Engine System	6WF1-TC		X	X		X		
Qingling ISUZU series	Engine System	6WG1-TC		X	X		X		
Qingling ISUZU series	Engine System	6WG1-TC(as of 2007)		X	X		X		
Qingling ISUZU series	Engine System	4JB1-TC engine(100P)		X	X		X		
Qingling ISUZU series	Engine System	4JB1-TCT/TC1 (100P)		X	X		X		
Qingling ISUZU series	Engine System	ISUZU 4JB1 100P National IV		X	X		X		
Qingling ISUZU series	Engine System	4JB1IT Engine (Bosch Diesel)		X	X		X		
Qingling ISUZU series	Engine System	4KH1 TCG40		X	X		X		
Qingling ISUZU series	Engine System	600P 4KH1-TC engine		X	X		X		
Qingling ISUZU series	Engine System	4HK1 Euro IV (2011 N series)		X	X		X		
Qingling ISUZU series	Engine System	4HK1-TC (C/Rail NLT) 700P		X	X		X		
Qingling ISUZU series	Engine System	4HK1-TC (Euro IV)		X	X		X		
Qingling ISUZU series	Engine System	4HK1-TC(Euro 5)		X	X		X		
Qingling ISUZU series	Engine System	4HK1-TC (North America)	Engine system	X	X		X		
Qingling ISUZU series	Engine System	4HK1-TC (North America)	ABS	X	X		X		
Qingling ISUZU series	Engine System	4HK1-TC (North America)	AT	X	X		X		
Qingling ISUZU series	Engine System	4HK1/6HK1 Crail Euro2		X	X		X		
Qingling ISUZU series	Engine System	4HK1/6HK1 Crail Euro3		X	X		X		
Qingling ISUZU series	Engine System	DISEL CR EDC 4HK1		X	X		X		
Qingling ISUZU series	Engine System	DISEL CR EDC 4JJ1		X	X		X		
Qingling ISUZU series	Engine System	N series trucks	4HK1/4JJ1 CRail Euro2	X	X		X		
Qingling ISUZU series	Engine System	N series trucks	4HK1/4JJ1 CRail Euro3	X	X		X		
Qingling ISUZU series	Engine System	N series trucks	4HV1 CNG	X	X		X		
Qingling ISUZU series	Engine System	4JH1 diesel engine		X	X		X		
Qingling ISUZU series	Engine System	4JH1 TC (as of 2011)		X	X		X		
Qingling ISUZU series	Engine System	4JH1 TC		X	X		X		
Qingling ISUZU series	Engine System	4JH1-TC1		X	X		X		
Qingling ISUZU series	Engine System	4JH1-Tds		X	X		X		
Qingling ISUZU series	Engine System	4JH1-T DENSO		X	X		X		
Qingling ISUZU series	Engine System	4JJ1-TC 3.0L		X	X		X		
Qingling ISUZU series	Engine System	4JJ1-TC 3.0 (Delphi)		X	X		X		
Qingling ISUZU series	Engine System	4JI1-TC(Euro 4)		X	X		X		
Qingling ISUZU series	Engine System	4JK1-TC 2.5L		X	X		X		
Qingling ISUZU series	Engine System	4JX1(3.0 L4)		X	X		X		
Qingling ISUZU series	Engine System	4JG2 (LPG)		X	X		X		
Qingling ISUZU series	Engine System	4HG1 (LPG)		X	X		X		
Qingling ISUZU series	Engine System	4HL TC		X	X		X		
Qingling ISUZU series	Engine System	4HL1		X	X		X		
Qingling ISUZU series	Engine System	4HL1-NA		X	X		X		
Qingling ISUZU series	Engine System	4HJ1-TC		X	X		X		
Qingling ISUZU series	Engine System	4HJ1		X	X		X		
Qingling ISUZU series	Engine System	Perkins		X	X		X		
Qingling ISUZU series	Engine System	Qingling 100P BOSCH EDC17C55 system national IV		X	X		X		
Qingling ISUZU series	Engine System	4ZE3/4ZE4 Engine		X	X		X		
Qingling ISUZU series	Engine System	4HF1(CNG)		X	X		X		

Region	Series&Year	System	Model	ECU INFO	DTC	DTC Freeze	Data List	Actualions	Spec. Func.
Qingling ISUZU series	Engine System	BOSCH Diesel Engine		X X		X			
Qingling ISUZU series	Transmission System	4HK1-TC Transmission		X X		X			
Qingling ISUZU series	Transmission System	4HK1 TC(AT)		X X		X			
Qingling ISUZU series	Transmission System	ELF truck Smoother (Ex) Transmission		X X		X			
Qingling ISUZU series	Transmission System	Smoother		X X		X			
Qingling ISUZU series	Chassis	6WFI ABS system		X X		X			
Qingling ISUZU series	Chassis	4HK1-TC ABS		X X		X			
Qingling ISUZU series	Chassis	ABS2		X X		X			
Qingling ISUZU series	Chassis	Chassis electronic suspension control		X X		X			
Qingling ISUZU series	Chassis	Hill Start Assist/fuel shutoff at forced idle conditions		X X		X			
Qingling ISUZU series	Body	Immobilizer		X X		X			
Qingling ISUZU series	Body	Airbag		X X		X			
ELF series	Engine System	4HK1-TC (Euro 2/3)		X X		X			
ELF series	Engine System	4J11-TC(Euro 4)		X X		X			
ELF series	Engine System	4J11-TC (Euro 5)		X X		X			
ELF series	Engine System	4HK1-TC (Euro IV)		X X		X			
ELF series	Engine System	4HK1-TC(Euro 5)		X X		X			
ELF series	Engine System	4HK1-TC (North America)		X X		X			
ELF series	Engine System	4J11CN(national IV 100P)		X X		X			
North American ISUZU series	2017	N-Series w/5.2L Diesel (4HK1)	Engine	X X		X			
North American ISUZU series	2017	N-Series w/5.2L Diesel (4HK1)	Transmission	X X		X			
North American ISUZU series	2017	N-Series w/5.2L Diesel (4HK1)	ABS	X X		X			
North American ISUZU series	2017	N-Series w/5.2L Diesel (4HK1)	Diesel Exhaust Fluid Control Module	X X		X			
North American ISUZU series	2017	N-Series w/5.2L Diesel (4HK1)	Mimanori ECU	X X		X			
North American ISUZU series	2017	N-Series w/5.2L Diesel (4HK1)	FMS CAN converter(if equipped)	X X		X			
North American ISUZU series	2017	Stripped Chassis w/3.0L Diesel(4J11)	Engine	X X		X			
North American ISUZU series	2017	Stripped Chassis w/3.0L Diesel(4J11)	Transmission	X X		X			
North American ISUZU series	2017	Stripped Chassis w/3.0L Diesel(4J11)	ABS	X X		X			
North American ISUZU series	2017	Stripped Chassis w/3.0L Diesel(4J11)	Diesel Exhaust Fluid Control Module	X X		X			
North American ISUZU series	2017	Stripped Chassis w/3.0L Diesel(4J11)	Mimanori ECU	X X		X			
North American ISUZU series	2017	Stripped Chassis w/3.0L Diesel(4J11)	FMS CAN converter(if equipped)	X X		X			
North American ISUZU series	2017	N-Series w/3.0L Diesel (4J11)	Engine	X X		X			
North American ISUZU series	2017	N-Series w/3.0L Diesel (4J11)	Transmission	X X		X			
North American ISUZU series	2017	N-Series w/3.0L Diesel (4J11)	ABS	X X		X			
North American ISUZU series	2017	N-Series w/3.0L Diesel (4J11)	Diesel Exhaust Fluid Control Module	X X		X			
North American ISUZU series	2017	N-Series w/3.0L Diesel (4J11)	Mimanori ECU	X X		X			
North American ISUZU series	2017	N-Series w/3.0L Diesel (4J11)	FMS CAN converter(if equipped)	X X		X			
North American ISUZU series	2016	N-Series w/5.2L Diesel (4HK1)	Engine	X X		X			
North American ISUZU series	2016	N-Series w/5.2L Diesel (4HK1)	Transmission	X X		X			
North American ISUZU series	2016	N-Series w/5.2L Diesel (4HK1)	ABS	X X		X			
North American ISUZU series	2016	N-Series w/5.2L Diesel (4HK1)	Diesel Exhaust Fluid Control Module	X X		X			
North American ISUZU series	2016	N-Series w/5.2L Diesel (4HK1)	Mimanori ECU	X X		X			
North American ISUZU series	2016	N-Series w/5.2L Diesel (4HK1)	FMS CAN converter(if equipped)	X X		X			
North American ISUZU series	2016	Stripped Chassis w/3.0L Diesel(4J11)	Engine	X X		X			
North American ISUZU series	2016	Stripped Chassis w/3.0L Diesel(4J11)	Transmission	X X		X			
North American ISUZU series	2016	Stripped Chassis w/3.0L Diesel(4J11)	ABS	X X		X			
North American ISUZU series	2016	Stripped Chassis w/3.0L Diesel(4J11)	Diesel Exhaust Fluid Control Module	X X		X			
North American ISUZU series	2016	Stripped Chassis w/3.0L Diesel(4J11)	Mimanori ECU	X X		X			
North American ISUZU series	2016	Stripped Chassis w/3.0L Diesel(4J11)	FMS CAN converter(if equipped)	X X		X			
North American ISUZU series	2016	N-Series w/3.0L Diesel (4J11)	Engine	X X		X			
North American ISUZU series	2016	N-Series w/3.0L Diesel (4J11)	Transmission	X X		X			
North American ISUZU series	2016	N-Series w/3.0L Diesel (4J11)	ABS	X X		X			

Region	Series&Year	System	Model	ECU INFO	DTC	DTC Freeze	Data List	Actualions	Spec. Func.
North American ISUZU series	2016	N-Series w/3.0L Diesel (4JJ1)	Diesel Exhaust Fluid Control Module	X	X		X		
North American ISUZU series	2016	N-Series w/3.0L Diesel (4JJ1)	Mimanori ECU	X	X		X		
North American ISUZU series	2016	N-Series w/3.0L Diesel (4JJ1)	FMS CAN converter(if equipped)	X	X		X		
North American ISUZU series	2016	N-Series w/6.0L Gas	Engine	X	X		X		
North American ISUZU series	2016	N-Series w/6.0L Gas	Transmission	X	X		X		
North American ISUZU series	2016	N-Series w/6.0L Gas	ABS	X	X		X		
North American ISUZU series	2016	N-Series w/6.0L Gas	PIM Data Display	X	X		X		
North American ISUZU series	2015	N-Series w/5.2L Diesel (4HK1)	Engine	X	X		X		
North American ISUZU series	2015	N-Series w/5.2L Diesel (4HK1)	Transmission	X	X		X		
North American ISUZU series	2015	N-Series w/5.2L Diesel (4HK1)	ABS	X	X		X		
North American ISUZU series	2015	N-Series w/5.2L Diesel (4HK1)	Diesel Exhaust Fluid Control Module	X	X		X		
North American ISUZU series	2015	N-Series w/5.2L Diesel (4HK1)	Mimanori ECU	X	X		X		
North American ISUZU series	2015	N-Series w/5.2L Diesel (4HK1)	FMS CAN converter(if equipped)	X	X		X		
North American ISUZU series	2015	Stripped Chassis w/3.0L Diesel(4JJ1)	Engine	X	X		X		
North American ISUZU series	2015	Stripped Chassis w/3.0L Diesel(4JJ1)	Transmission	X	X		X		
North American ISUZU series	2015	Stripped Chassis w/3.0L Diesel(4JJ1)	ABS	X	X		X		
North American ISUZU series	2015	Stripped Chassis w/3.0L Diesel(4JJ1)	Diesel Exhaust Fluid Control Module	X	X		X		
North American ISUZU series	2015	Stripped Chassis w/3.0L Diesel(4JJ1)	Mimanori ECU	X	X		X		
North American ISUZU series	2015	Stripped Chassis w/3.0L Diesel(4JJ1)	FMS CAN converter(if equipped)	X	X		X		
North American ISUZU series	2015	N-Series w/3.0L Diesel (4JJ1)	Engine	X	X		X		
North American ISUZU series	2015	N-Series w/3.0L Diesel (4JJ1)	Transmission	X	X		X		
North American ISUZU series	2015	N-Series w/3.0L Diesel (4JJ1)	ABS	X	X		X		
North American ISUZU series	2015	N-Series w/3.0L Diesel (4JJ1)	Diesel Exhaust Fluid Control Module	X	X		X		
North American ISUZU series	2015	N-Series w/3.0L Diesel (4JJ1)	Mimanori ECU	X	X		X		
North American ISUZU series	2015	N-Series w/3.0L Diesel (4JJ1)	FMS CAN converter(if equipped)	X	X		X		
North American ISUZU series	2015	N-Series w/6.0L Gas	Engine	X	X		X		
North American ISUZU series	2015	N-Series w/6.0L Gas	Transmission	X	X		X		
North American ISUZU series	2015	N-Series w/6.0L Gas	ABS	X	X		X		
North American ISUZU series	2015	N-Series w/6.0L Gas	PIM Data Display	X	X		X		
North American ISUZU series	2014	N-Series w/5.2L Diesel (4HK1)	Engine	X	X		X		
North American ISUZU series	2014	N-Series w/5.2L Diesel (4HK1)	Transmission	X	X		X		
North American ISUZU series	2014	N-Series w/5.2L Diesel (4HK1)	ABS	X	X		X		
North American ISUZU series	2014	N-Series w/5.2L Diesel (4HK1)	Diesel Exhaust Fluid Control Module	X	X		X		
North American ISUZU series	2014	N-Series w/5.2L Diesel (4HK1)	Mimanori ECU	X	X		X		
North American ISUZU series	2014	N-Series w/5.2L Diesel (4HK1)	FMS CAN converter(if equipped)	X	X		X		
North American ISUZU series	2014	Stripped Chassis w/3.0L Diesel(4JJ1)	Engine	X	X		X		
North American ISUZU series	2014	Stripped Chassis w/3.0L Diesel(4JJ1)	Transmission	X	X		X		
North American ISUZU series	2014	Stripped Chassis w/3.0L Diesel(4JJ1)	ABS	X	X		X		
North American ISUZU series	2014	Stripped Chassis w/3.0L Diesel(4JJ1)	Diesel Exhaust Fluid Control Module	X	X		X		
North American ISUZU series	2014	Stripped Chassis w/3.0L Diesel(4JJ1)	Mimanori ECU	X	X		X		
North American ISUZU series	2014	Stripped Chassis w/3.0L Diesel(4JJ1)	FMS CAN converter(if equipped)	X	X		X		
North American ISUZU series	2014	N-Series w/3.0L Diesel (4JJ1)	Engine	X	X		X		
North American ISUZU series	2014	N-Series w/3.0L Diesel (4JJ1)	Transmission	X	X		X		
North American ISUZU series	2014	N-Series w/3.0L Diesel (4JJ1)	ABS	X	X		X		
North American ISUZU series	2014	N-Series w/3.0L Diesel (4JJ1)	Diesel Exhaust Fluid Control Module	X	X		X		
North American ISUZU series	2014	N-Series w/3.0L Diesel (4JJ1)	Mimanori ECU	X	X		X		
North American ISUZU series	2014	N-Series w/3.0L Diesel (4JJ1)	FMS CAN converter(if equipped)	X	X		X		
North American ISUZU series	2014	N-Series w/6.0L Gas	Engine	X	X		X		
North American ISUZU series	2014	N-Series w/6.0L Gas	Transmission	X	X		X		
North American ISUZU series	2014	N-Series w/6.0L Gas	ABS	X	X		X		

Region	Series&Year	System	Model	ECU INFO	DTC	DTC Freeze	Data List	Actualions	Spec. Func.
North American ISUZU series	2014	N-Series w/6.0L Gas	PIM Data Display	X	X		X		
North American ISUZU series	2013	N-Series w/5.2L Diesel (4HK1)	Engine	X	X		X		
North American ISUZU series	2013	N-Series w/5.2L Diesel (4HK1)	Transmission	X	X		X		
North American ISUZU series	2013	N-Series w/5.2L Diesel (4HK1)	ABS	X	X		X		
North American ISUZU series	2013	N-Series w/5.2L Diesel (4HK1)	Diesel Exhaust Fluid Control Module	X	X		X		
North American ISUZU series	2013	N-Series w/5.2L Diesel (4HK1)	Mimanori ECU	X	X		X		
North American ISUZU series	2013	Stripped Chassis w/3.0L Diesel(4JJ1)	Engine	X	X		X		
North American ISUZU series	2013	Stripped Chassis w/3.0L Diesel(4JJ1)	Transmission	X	X		X		
North American ISUZU series	2013	Stripped Chassis w/3.0L Diesel(4JJ1)	ABS	X	X		X		
North American ISUZU series	2013	Stripped Chassis w/3.0L Diesel(4JJ1)	Diesel Exhaust Fluid Control Module	X	X		X		
North American ISUZU series	2013	Stripped Chassis w/3.0L Diesel(4JJ1)	Mimanori ECU	X	X		X		
North American ISUZU series	2013	Stripped Chassis w/3.0L Diesel(4JJ1)	FMS CAN converter(if equipped)	X	X		X		
North American ISUZU series	2013	N-Series w/3.0L Diesel (4JJ1)	Engine	X	X		X		
North American ISUZU series	2013	N-Series w/3.0L Diesel (4JJ1)	Transmission	X	X		X		
North American ISUZU series	2013	N-Series w/3.0L Diesel (4JJ1)	ABS	X	X		X		
North American ISUZU series	2013	N-Series w/3.0L Diesel (4JJ1)	Diesel Exhaust Fluid Control Module	X	X		X		
North American ISUZU series	2013	N-Series w/3.0L Diesel (4JJ1)	Mimanori ECU	X	X		X		
North American ISUZU series	2013	N-Series w/3.0L Diesel (4JJ1)	FMS CAN converter(if equipped)	X	X		X		
North American ISUZU series	2013	N-Series w/6.0L Gas	Engine	X	X		X		
North American ISUZU series	2013	N-Series w/6.0L Gas	Transmission	X	X		X		
North American ISUZU series	2013	N-Series w/6.0L Gas	ABS	X	X		X		
North American ISUZU series	2013	N-Series w/6.0L Gas	PIM Data Display	X	X		X		
North American ISUZU series	2012	N-Series w/5.2L Diesel (4HK1)	Engine	X	X		X		
North American ISUZU series	2012	N-Series w/5.2L Diesel (4HK1)	Transmission	X	X		X		
North American ISUZU series	2012	N-Series w/5.2L Diesel (4HK1)	ABS	X	X		X		
North American ISUZU series	2012	N-Series w/5.2L Diesel (4HK1)	Diesel Exhaust Fluid Control Module	X	X		X		
North American ISUZU series	2012	N-Series w/5.2L Diesel (4HK1)	Mimanori ECU	X	X		X		
North American ISUZU series	2012	Stripped Chassis w/3.0L Diesel(4JJ1)	Engine	X	X		X		
North American ISUZU series	2012	Stripped Chassis w/3.0L Diesel(4JJ1)	Transmission	X	X		X		
North American ISUZU series	2012	Stripped Chassis w/3.0L Diesel(4JJ1)	ABS	X	X		X		
North American ISUZU series	2012	Stripped Chassis w/3.0L Diesel(4JJ1)	Diesel Exhaust Fluid Control Module	X	X		X		
North American ISUZU series	2012	Stripped Chassis w/3.0L Diesel(4JJ1)	Mimanori ECU	X	X		X		
North American ISUZU series	2012	N-Series w/3.0L Diesel (4JJ1)	Engine	X	X		X		
North American ISUZU series	2012	N-Series w/3.0L Diesel (4JJ1)	Transmission	X	X		X		
North American ISUZU series	2012	N-Series w/3.0L Diesel (4JJ1)	ABS	X	X		X		
North American ISUZU series	2012	N-Series w/3.0L Diesel (4JJ1)	Diesel Exhaust Fluid Control Module	X	X		X		
North American ISUZU series	2012	N-Series w/3.0L Diesel (4JJ1)	Mimanori ECU	X	X		X		
North American ISUZU series	2012	N-Series w/6.0L Gas	Engine	X	X		X		
North American ISUZU series	2012	N-Series w/6.0L Gas	Transmission	X	X		X		
North American ISUZU series	2012	N-Series w/6.0L Gas	ABS	X	X		X		
North American ISUZU series	2012	N-Series w/6.0L Gas	PIM Data Display	X	X		X		
North American ISUZU series	2011	N-Series w/5.2L Diesel (4HK1)	Engine	X	X		X		
North American ISUZU series	2011	N-Series w/5.2L Diesel (4HK1)	Transmission	X	X		X		
North American ISUZU series	2011	N-Series w/5.2L Diesel (4HK1)	ABS	X	X		X		
North American ISUZU series	2011	N-Series w/5.2L Diesel (4HK1)	Diesel Exhaust Fluid Control Module	X	X		X		
North American ISUZU series	2011	N-Series w/5.2L Diesel (4HK1)	Mimanori ECU	X	X		X		
North American ISUZU series	2011	N-Series w/3.0L Diesel (4JJ1)	Engine	X	X		X		
North American ISUZU series	2011	N-Series w/3.0L Diesel (4JJ1)	Transmission	X	X		X		
North American ISUZU series	2011	N-Series w/3.0L Diesel (4JJ1)	ABS	X	X		X		
North American ISUZU series	2011	N-Series w/3.0L Diesel (4JJ1)	Diesel Exhaust Fluid Control Module	X	X		X		

Region	Series&Year	System	Model	ECU INFO	DTC	DTC Freeze	Data List	Actualions	Spec. Func.
North American ISUZU series	2011	N-Series w/3.0L Diesel (4JJ1)	Mimanori ECU	X	X		X		
North American ISUZU series	2010	N/W Series w/5.2L Diesel(4HK1)	Engine	X	X		X		
North American ISUZU series	2010	N/W Series w/5.2L Diesel(4HK1)	Transmission	X	X		X		
North American ISUZU series	2010	N/W Series w/5.2L Diesel(4HK1)	ABS	X	X		X		
North American ISUZU series	2009	N/W Series w/5.2L Diesel(4HK1)	Engine	X	X		X		
North American ISUZU series	2009	N/W Series w/5.2L Diesel(4HK1)	Transmission	X	X		X		
North American ISUZU series	2009	N/W Series w/5.2L Diesel(4HK1)	ABS	X	X		X		
North American ISUZU series	2009	N/W Series w/6.0L Gas	Engine	X	X		X		
North American ISUZU series	2009	N/W Series w/6.0L Gas	Transmission	X	X		X		
North American ISUZU series	2009	N/W Series w/6.0L Gas	ABS	X	X		X		
North American ISUZU series	2009	N/W Series w/6.0L Gas	PIM Data Display	X	X		X		
North American ISUZU series	2009	F/T Series w/7.8L Diesel (6HK1)	F/T Series w/7.8L Diesel (6HK1) AUTO	X	X		X		
North American ISUZU series	2009	F/T Series w/7.8L Diesel (6HK1)	F/T Series w/7.8L Diesel (6HK1) Manual	X	X		X		
North American ISUZU series	2009	C-Series w/7.8L Diesel (6HK1)	C-Series w/7.8L Diesel (6HK1) AUTO	X	X		X		
North American ISUZU series	2009	C-Series w/7.8L Diesel (6HK1)	C-Series w/7.8L Diesel (6HK1) Manual	X	X		X		
North American ISUZU series	2008	N/W Series w/5.2L Diesel(4HK1)	Engine	X	X		X		
North American ISUZU series	2008	N/W Series w/5.2L Diesel(4HK1)	Transmission	X	X		X		
North American ISUZU series	2008	N/W Series w/5.2L Diesel(4HK1)	ABS	X	X		X		
North American ISUZU series	2008	N/W Series w/6.0L Gas	Engine	X	X		X		
North American ISUZU series	2008	N/W Series w/6.0L Gas	Transmission	X	X		X		
North American ISUZU series	2008	N/W Series w/6.0L Gas	ABS	X	X		X		
North American ISUZU series	2008	N/W Series w/6.0L Gas	PIM Data Display	X	X		X		
North American ISUZU series	2008	F/T Series w/7.8L Diesel (6HK1)	F/T Series w/7.8L Diesel (6HK1) AUTO	X	X		X		
North American ISUZU series	2008	F/T Series w/7.8L Diesel (6HK1)	F/T Series w/7.8L Diesel (6HK1) Manual	X	X		X		
North American ISUZU series	2008	C-Series w/7.8L Diesel (6HK1)	C-Series w/7.8L Diesel (6HK1) AUTO	X	X		X		
North American ISUZU series	2008	C-Series w/7.8L Diesel (6HK1)	C-Series w/7.8L Diesel (6HK1) Manual	X	X		X		
North American ISUZU series	2007	N/W Series w/5.2L Diesel(4HK1)	Engine	X	X		X		
North American ISUZU series	2007	N/W Series w/5.2L Diesel(4HK1)	Transmission	X	X		X		
North American ISUZU series	2007	N/W Series w/5.2L Diesel(4HK1)	ABS	X	X		X		
North American ISUZU series	2007	N/W Series w/6.0L Gas	Engine	X	X		X		
North American ISUZU series	2007	N/W Series w/6.0L Gas	Transmission	X	X		X		
North American ISUZU series	2007	N/W Series w/6.0L Gas	ABS	X	X		X		
North American ISUZU series	2007	F/T Series w/7.8L Diesel (6HK1)	Engine	X	X		X		
North American ISUZU series	2007	F/T Series w/7.8L Diesel (6HK1)	Transmission	X	X		X		
North American ISUZU series	2007	F/T Series w/7.8L Diesel (6HK1)	ABS	X	X		X		
North American ISUZU series	2007	F/T Series w/7.8L Diesel (6HK1)	IPC Data Display	X	X		X		
North American ISUZU series	2007	F/T Series w/7.8L Diesel (6HK1)	Chime Data Display	X	X		X		
North American ISUZU series	2007	F/T Series w/7.8L Diesel (6HK1)	SDGM Data Display(If Equipped)	X	X		X		
North American ISUZU series	2007	C-Series w/7.8L Diesel (6HK1)	Engine	X	X		X		
North American ISUZU series	2007	C-Series w/7.8L Diesel (6HK1)	Transmission	X	X		X		
North American ISUZU series	2007	C-Series w/7.8L Diesel (6HK1)	ABS	X	X		X		
North American ISUZU series	2007	C-Series w/7.8L Diesel (6HK1)	IPC Data Display	X	X		X		
North American ISUZU series	2007	C-Series w/7.8L Diesel (6HK1)	Chime Data Display	X	X		X		
North American ISUZU series	2007	C-Series w/7.8L Diesel (6HK1)	SDGM Data Display(If Equipped)	X	X		X		
North American ISUZU series	2006	N/W Series w/5.2L Diesel(4HK1)	Engine	X	X		X		
North American ISUZU series	2006	N/W Series w/5.2L Diesel(4HK1)	Transmission	X	X		X		
North American ISUZU series	2006	N/W Series w/5.2L Diesel(4HK1)	ABS	X	X		X		
North American ISUZU series	2006	N/W Series w/6.0L Gas	Engine	X	X		X		
North American ISUZU series	2006	N/W Series w/6.0L Gas	Transmission	X	X		X		
North American ISUZU series	2006	N/W Series w/6.0L Gas	ABS	X	X		X		

Region	Series&Year	System	Model	ECU INFO	DTC	DTC Freeze	Data List	Actualions	Spec. Func.
North American ISUZU series	2003	C-Series w/7.8L Diesel (6HK1)	ABS	X X			X		
North American ISUZU series	2003	C-Series w/7.8L Diesel (6HK1)	IPC Data Display	X X			X		
North American ISUZU series	2003	C-Series w/7.8L Diesel (6HK1)	Chime Data Display	X X			X		
North American ISUZU series	2003	C-Series w/7.8L Diesel (6HK1)	SDGM Data Display(If Equipped)	X X			X		
North American ISUZU series	2003	N/W Series w/5.7L (CAL) Gas	Engine	X X			X		
North American ISUZU series	2003	N/W Series w/5.7L (CAL) Gas	Transmission	X X			X		
North American ISUZU series	2003	N/W Series w/5.7L (CAL) Gas	ABS	X X			X		
North American ISUZU series	2003	N/W Series w/5.7L (FED) Gas	Engine	X X			X		
North American ISUZU series	2003	N/W Series w/5.7L (FED) Gas	Transmission	X X			X		
North American ISUZU series	2003	N/W Series w/5.7L (FED) Gas	ABS	X X			X		
North American ISUZU series	2002	N/W Series w/5.7L (CAL) Gas	Engine	X X			X		
North American ISUZU series	2002	N/W Series w/5.7L (CAL) Gas	Transmission	X X			X		
North American ISUZU series	2002	N/W Series w/5.7L (CAL) Gas	ABS	X X			X		
North American ISUZU series	2002	N/W Series w/5.7L (FED) Gas	Engine	X X			X		
North American ISUZU series	2002	N/W Series w/5.7L (FED) Gas	Transmission	X X			X		
North American ISUZU series	2002	N/W Series w/5.7L (FED) Gas	ABS	X X			X		
North American ISUZU series	2001	N/W Series w/5.7L (CAL) Gas	Engine	X X			X		
North American ISUZU series	2001	N/W Series w/5.7L (CAL) Gas	Transmission	X X			X		
North American ISUZU series	2001	N/W Series w/5.7L (CAL) Gas	ABS	X X			X		
North American ISUZU series	2001	N/W Series w/5.7L (FED) Gas	Engine	X X			X		
North American ISUZU series	2001	N/W Series w/5.7L (FED) Gas	Transmission	X X			X		
North American ISUZU series	2001	N/W Series w/5.7L (FED) Gas	ABS	X X			X		
North American ISUZU series	2000	N/W Series w/5.7L (CAL) Gas	Engine	X X			X		
North American ISUZU series	2000	N/W Series w/5.7L (CAL) Gas	Transmission	X X			X		
North American ISUZU series	2000	N/W Series w/5.7L (CAL) Gas	ABS	X X			X		
North American ISUZU series	2000	N/W Series w/5.7L (FED) Gas	Engine	X X			X		
North American ISUZU series	2000	N/W Series w/5.7L (FED) Gas	Transmission	X X			X		
North American ISUZU series	2000	N/W Series w/5.7L (FED) Gas	ABS	X X			X		
North American ISUZU series	1999	N/W Series w/5.7L (CAL) Gas	Engine	X X			X		
North American ISUZU series	1999	N/W Series w/5.7L (CAL) Gas	Transmission	X X			X		
North American ISUZU series	1999	N/W Series w/5.7L (CAL) Gas	ABS	X X			X		
North American ISUZU series	1999	N/W Series w/5.7L (FED) Gas	Engine	X X			X		
North American ISUZU series	1999	N/W Series w/5.7L (FED) Gas	Transmission	X X			X		
North American ISUZU series	1999	N/W Series w/5.7L (FED) Gas	ABS	X X			X		
North American ISUZU series	1998	N/W Series w/5.7L (CAL) Gas	Engine	X X			X		
North American ISUZU series	1998	N/W Series w/5.7L (CAL) Gas	Transmission	X X			X		
North American ISUZU series	1998	N/W Series w/5.7L (FED) Gas	Engine	X X			X		
North American ISUZU series	1998	N/W Series w/5.7L (FED) Gas	Transmission	X X			X		
Euro 5, Euro 4, Euro 3, Euro 2 series	[F]2015	N-Series w/5.2L Diesel(4HK1)	Engine	X X			X X		Read and Write Injector code Read and Write Engine Serial Number
Euro 5, Euro 4, Euro 3, Euro 2 series	[F]2015	N-Series w/5.2L Diesel(4HK1)	TRANSMISSION		X		X X		
Euro 5, Euro 4, Euro 3, Euro 2 series	[F]2015	N-Series w/5.2L Diesel(4HK1)	ABS		X		X		
Euro 5, Euro 4, Euro 3, Euro 2 series	[F]2015	N-Series w/5.2L Diesel(4HK1)	Mimamori ECU		X		X		
Euro 5, Euro 4, Euro 3, Euro 2 series	[F]2015	N-Series w/5.2L Diesel(4HK1)	Diesel Exhaust Fluid Control	X	X		X		
Euro 5, Euro 4, Euro 3, Euro 2 series	[E]2014	N-Series w/5.2L Diesel(4HK1)	Engine	X X			X X		Read and Write Injector code Read and Write Engine Serial Number
Euro 5, Euro 4, Euro 3, Euro 2 series	[E]2014	N-Series w/5.2L Diesel(4HK1)	Engine-EUR05	X X			X X		Read and Write Engine Serial Number
Euro 5, Euro 4, Euro 3, Euro 2 series	[E]2014	N-Series w/5.2L Diesel(4HK1)	TRANSMISSION		X		X X		
Euro 5, Euro 4, Euro 3, Euro 2 series	[E]2014	N-Series w/5.2L Diesel(4HK1)	ABS		X		X		
Euro 5, Euro 4, Euro 3, Euro 2 series	[E]2014	N-Series w/5.2L Diesel(4HK1)	Mimamori ECU		X		X		
Euro 5, Euro 4, Euro 3, Euro 2 series	[E]2014	N-Series w/5.2L Diesel(4HK1)	Diesel Exhaust Fluid Control	X X			X		
Euro 5, Euro 4, Euro 3, Euro 2 series	[E]2014	N-Series w/3.0L Diesel(4J1J)	Engine	X X			X X		Read and Write Injector code
Euro 5, Euro 4, Euro 3, Euro 2 series	[E]2014	N-Series w/3.0L Diesel(4J1J)	TRANSMISSION		X		X X		
Euro 5, Euro 4, Euro 3, Euro 2 series	[E]2014	N-Series w/3.0L Diesel(4J1J)	ABS		X		X		
Euro 5, Euro 4, Euro 3, Euro 2 series	[E]2014	N-Series w/3.0L Diesel(4J1J)	Mimamori ECU		X		X		
Euro 5, Euro 4, Euro 3, Euro 2 series	[E]2014	N-Series w/3.0L Diesel(4J1J)	Diesel Exhaust Fluid Control	X X			X		
Euro 5, Euro 4, Euro 3, Euro 2 series	[D]2013	N-Series w/5.2L Diesel(4HK1)	Engine	X X			X X		Read and Write Injector code Read and Write Engine Serial Number
Euro 5, Euro 4, Euro 3, Euro 2 series	[D]2013	N-Series w/5.2L Diesel(4HK1)	TRANSMISSION		X		X X		
Euro 5, Euro 4, Euro 3, Euro 2 series	[D]2013	N-Series w/5.2L Diesel(4HK1)	ABS		X		X		
Euro 5, Euro 4, Euro 3, Euro 2 series	[D]2013	N-Series w/5.2L Diesel(4HK1)	Mimamori ECU		X		X		
Euro 5, Euro 4, Euro 3, Euro 2 series	[D]2013	N-Series w/5.2L Diesel(4HK1)	Diesel Exhaust Fluid Control	X X			X		
Euro 5, Euro 4, Euro 3, Euro 2 series	[D]2013	N-Series w/3.0L Diesel(4J1J)	Engine	X X			X X		Read and Write Injector code

Region	Series&Year	System	Model	ECU INFO	DTC	DTC Freeze	Data List	Actuations	Spec. Func.
Euro 5, Euro 4, Euro 3, Euro 2 series	[D]2013	N-Series w/3.0L Diesel(4J11)	TRANSMISSION		X		X	X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[D]2013	N-Series w/3.0L Diesel(4J11)	ABS		X			X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[D]2013	N-Series w/3.0L Diesel(4J11)	Mimamori ECU		X			X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[D]2013	N-Series w/3.0L Diesel(4J11)	Diesel Exhaust Fluid Control	X	X			X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[C]2012	N-Series w/5.2L Diesel(4HK1)	Engine	X	X		X	X	Read and Write Injector code Read and Write Engine Serial Number
Euro 5, Euro 4, Euro 3, Euro 2 series	[C]2012	N-Series w/5.2L Diesel(4HK1)	TRANSMISSION		X		X	X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[C]2012	N-Series w/5.2L Diesel(4HK1)	ABS		X			X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[C]2012	N-Series w/5.2L Diesel(4HK1)	Mimamori ECU		X			X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[C]2012	N-Series w/5.2L Diesel(4HK1)	Diesel Exhaust Fluid Control	X	X			X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[C]2012	N-Series w/3.0L Diesel(4J11)	Engine	X	X		X	X	Read and Write Injector code
Euro 5, Euro 4, Euro 3, Euro 2 series	[C]2012	N-Series w/3.0L Diesel(4J11)	TRANSMISSION		X		X	X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[C]2012	N-Series w/3.0L Diesel(4J11)	ABS		X			X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[C]2012	N-Series w/3.0L Diesel(4J11)	Mimamori ECU		X			X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[C]2012	N-Series w/3.0L Diesel(4J11)	Diesel Exhaust Fluid Control	X	X			X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[B]2011	N-Series w/5.2L Diesel(4HK1)	Engine	X	X		X	X	Read and Write Injector code Read and Write Engine Serial Number
Euro 5, Euro 4, Euro 3, Euro 2 series	[B]2011	N-Series w/5.2L Diesel(4HK1)	TRANSMISSION		X		X	X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[B]2011	N-Series w/5.2L Diesel(4HK1)	ABS		X			X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[B]2011	N-Series w/5.2L Diesel(4HK1)	Mimamori ECU		X			X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[B]2011	N-Series w/5.2L Diesel(4HK1)	Diesel Exhaust Fluid Control	X	X			X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[B]2011	N-Series w/3.0L Diesel(4J11)	Engine	X	X		X	X	Read and Write Injector code
Euro 5, Euro 4, Euro 3, Euro 2 series	[B]2011	N-Series w/3.0L Diesel(4J11)	TRANSMISSION		X		X	X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[B]2011	N-Series w/3.0L Diesel(4J11)	ABS		X			X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[B]2011	N-Series w/3.0L Diesel(4J11)	Mimamori ECU		X			X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[B]2011	N-Series w/3.0L Diesel(4J11)	Diesel Exhaust Fluid Control	X	X			X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[B]2011	F/G Series Truck	4HK1-TC (C/Rail)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[B]2011	F/G Series Truck	6HK1-TC (C/Rail)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[B]2011	F/G Series Truck	Smoother (TransTron)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[B]2011	F/G Series Truck	TRANSMISSION		X		X	X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[B]2011	F/G Series Truck	Immobiliser						
Euro 5, Euro 4, Euro 3, Euro 2 series	[B]2011	C/E Series Truck	6WG1-TC (C/Rail)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[B]2011	LT/LV Series Bus	6HK1-TC (C/Rail)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[B]2011	LT/LV Series Bus	TRANSMISSION		X		X	X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[B]2011	TF/UC Serie	2.5L 4JK1-TC (Delphi)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[B]2011	TF/UC Serie	2.5L 4JK1-TC (TransTron)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[B]2011	TF/UC Serie	3.0L 4JJ1-TC (Delphi)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[B]2011	TF/UC Serie	3.0L 4JJ1-TC (TransTron)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[B]2011	TF/UC Serie	TRANSMISSION		X		X	X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[B]2011	TF/UC Serie	AT IR405E						
Euro 5, Euro 4, Euro 3, Euro 2 series	[B]2011	TF/UC Serie	ABS						
Euro 5, Euro 4, Euro 3, Euro 2 series	[B]2011	TF/UC Serie	Immobiliser (Delphi)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[B]2011	TF/UC Serie	Immobiliser (Transtron)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[B]2011	TF/UC Serie	Airbag						
Euro 5, Euro 4, Euro 3, Euro 2 series	[B]2011	TF/UC Serie	Powertrain Interface Module						
Euro 5, Euro 4, Euro 3, Euro 2 series	[A]2010	N/W Series w/5.2L Diesel(4HK1)	4HK1-TC (C/Rail)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[A]2010	N/W Series w/5.2L Diesel(4HK1)	6HK1-TC (C/Rail)	X	X		X	X	Read and Write Injector code Speedometer Calibration Vehicle Speed Limit Setting Cruise Control Disable Setting Engine Protection Mode Enable Setting Engine Protection Mode Setting Exhaust Brake in Cruise Setting
Euro 5, Euro 4, Euro 3, Euro 2 series	[A]2010	N/W Series w/5.2L Diesel(4HK1)	Smoother (TransTron)		X		X	X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[A]2010	N/W Series w/5.2L Diesel(4HK1)	TRANSMISSION		X			X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	N/W Series w/6.0L Gas	Immobiliser	X	X		X	X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	N/W Series w/6.0L Gas	6WG1-TC (C/Rail)	X	X			X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	N/W Series w/5.2L Diesel(4HK1)	6HK1-TC (C/Rail)	X	X		X	X	Read and Write Injector code Speedometer Calibration Vehicle Speed Limit Setting Cruise Control Disable Setting Engine Protection Mode Enable Setting Engine Protection Mode Setting Exhaust Brake in Cruise Setting
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	N/W Series w/5.2L Diesel(4HK1)	TRANSMISSION		X		X	X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	F/G Series Truck	2.5L 4JK1-TC (Delphi)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	F/G Series Truck	2.5L 4JK1-TC (TransTron)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	F/G Series Truck	3.0L 4JJ1-TC (Delphi)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	F/G Series Truck	3.0L 4JJ1-TC (TransTron)		X		X	X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	F/G Series Truck	TRANSMISSION						
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	C/E Series Truck	AT IR405E						
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	LT/LV Series Bus	ABS						
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	LT/LV Series Bus	Immobiliser (Delphi)		X		X	X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	TF/UC Serie	Immobiliser (Transtron)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	TF/UC Serie	Airbag						
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	TF/UC Serie	Powertrain Interface Module						
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	TF/UC Serie	4HK1-TC (C/Rail)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	TF/UC Serie	6HK1-TC (C/Rail)		X		X	X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	TF/UC Serie	Smoother (TransTron)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	TF/UC Serie	TRANSMISSION		X			X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	TF/UC Serie	Immobiliser						
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	TF/UC Serie	6WG1-TC (C/Rail)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	TF/UC Serie	6HK1-TC (C/Rail)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	TF/UC Serie	TRANSMISSION						
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	N/W Series w/6.0L Gas	2.5L 4JK1-TC (Delphi)	X	X		X	X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	N/W Series w/6.0L Gas	2.5L 4JK1-TC (TransTron)	X	X			X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	N/W Series w/5.2L Diesel(4HK1)	3.0L 4JJ1-TC (Delphi)	X	X		X	X	Read and Write Injector code Speedometer Calibration Vehicle Speed Limit Setting Cruise Control Disable Setting Engine Protection Mode Enable Setting Engine Protection Mode Setting Exhaust Brake in Cruise Setting
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	N/W Series w/5.2L Diesel(4HK1)	3.0L 4JJ1-TC (TransTron)		X		X	X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	F/G Series Truck	TRANSMISSION						
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	F/G Series Truck	AT IR405E						
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	F/G Series Truck	ABS						
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	F/G Series Truck	Immobiliser (Delphi)		X		X	X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	F/G Series Truck	Immobiliser (Transtron)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	C/E Series Truck	Airbag						
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	LT/LV Series Bus	Powertrain Interface Module						

Region	Series&Year	System	Model	ECU INFO	DTC	DTC Freeze	Data List	Actuals	Spec. Func.
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	LT/LV Series Bus	4HK1-TC (C/Rail)		X		X	X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	TF/UC Serie	6HK1-TC (C/Rail)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	TF/UC Serie	Smoother (TransTron)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	TF/UC Serie	TRANSMISSION						
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	TF/UC Serie	Immobiliser						
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	TF/UC Serie	6WG1-TC (C/Rail)		X		X	X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	TF/UC Serie	6HK1-TC (C/Rail)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	TF/UC Serie	TRANSMISSION		X			X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	TF/UC Serie	2.5L 4JK1-TC (Delphi)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	TF/UC Serie	2.5L 4JK1-TC (TransTron)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	TF/UC Serie	3.0L 4JJ1-TC (Delphi)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	TF/UC Serie	3.0L 4JJ1-TC (TransTron)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[7]2007	N/W Series w/5.2L Diesel (4HK1)	TRANSMISSION						
Euro 5, Euro 4, Euro 3, Euro 2 series	[7]2007	N/W Series w/5.2L Diesel (4HK1)	AT JR405E		X		X	X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[7]2007	F/G Series Truck	ABS						
Euro 5, Euro 4, Euro 3, Euro 2 series	[7]2007	F/G Series Truck	Immobiliser (Delphi)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[7]2007	F/G Series Truck	Immobiliser (Transtron)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[7]2007	F/G Series Truck	Airbag		X		X	X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[7]2007	F/G Series Truck	Powertrain Interface Module						
Euro 5, Euro 4, Euro 3, Euro 2 series	[7]2007	C/E Series Truck	TRANSMISSION						
Euro 5, Euro 4, Euro 3, Euro 2 series	[7]2007	LT/LV Series Bus	ABS						
Euro 5, Euro 4, Euro 3, Euro 2 series	[7]2007	LT/LV Series Bus	Immobiliser		X		X	X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[7]2007	TF/UC Serie	Airbag						
Euro 5, Euro 4, Euro 3, Euro 2 series	[7]2007	TF/UC Serie	Powertrain Interface Module						
Euro 5, Euro 4, Euro 3, Euro 2 series	[7]2007	TF/UC Serie	AT JR405E						
Euro 5, Euro 4, Euro 3, Euro 2 series	[7]2007	TF/UC Serie	4HK1 (C/Rail Euro2)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[7]2007	TF/UC Serie	4JJ1 (C/Rail Euro2)		X		X	X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[7]2007	TF/UC Serie	4HK1 (C/Rail Euro3)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[7]2007	TF/UC Serie	4JJ1 (C/Rail Euro3)		X			X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[7]2007	TF/UC Serie	4HV1 (CNG)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[7]2007	TF/UC Serie	4HK1 (C/Rail Euro2)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[7]2007	TF/UC Serie	6HK1 (C/Rail Euro2)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[7]2007	TF/UC Serie	4HK1 (C/Rail Euro3)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[6]2006	TF/UC Serie	6HK1 (C/Rail Euro3)		X		X	X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[6]2006	TF/UC Serie	6WF1-TC (C/Rail)		X			X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[6]2006	TF/UC Serie	ESC (with EBS)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[6]2006	TF/UC Serie	ABS 6						
Euro 5, Euro 4, Euro 3, Euro 2 series	[6]2006	TF/UC Serie	AT JR405E						
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	IF/UC Serie	4HK1 (C/Rail Euro2)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	N Series Truck	4JJ1 (C/Rail Euro2)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	N Series Truck	4HK1 (C/Rail Euro3)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	N Series Truck	4JJ1 (C/Rail Euro3)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	N Series Truck	4HV1 (CNG)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	N Series Truck	4HK1 (C/Rail Euro2)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	F/G Series Truck	6HK1 (C/Rail Euro2)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	F/G Series Truck	4HK1 (C/Rail Euro3)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	F/G Series Truck	6HK1 (C/Rail Euro3)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	F/G Series Truck	6WF1-TC (C/Rail)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	(C*, E*, L*, F*) Heavy-Medium Duty	ESC (with EBS)		X	X		X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	(C*, E*, L*, F*) Heavy-Medium Duty	ABS 6		X	X		X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[9]2009	(C*, E*, L*, F*) Heavy-Medium Duty	AT JR405E		X	X		X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	IF/UC Serie	4HK1 (C/Rail Euro2)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	N Series Truck	4JJ1 (C/Rail Euro2)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	N Series Truck	4HK1 (C/Rail Euro3)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	N Series Truck	4JJ1 (C/Rail Euro3)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	N Series Truck	4HV1 (CNG)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	N Series Truck	4HK1 (C/Rail Euro2)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	F/G Series Truck	6HK1 (C/Rail Euro2)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	F/G Series Truck	4HK1 (C/Rail Euro3)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	F/G Series Truck	6HK1 (C/Rail Euro3)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	F/G Series Truck	6WF1-TC (C/Rail)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	(C*, E*, L*, F*) Heavy-Medium Duty	ESC (with EBS)		X	X		X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	(C*, E*, L*, F*) Heavy-Medium Duty	ABS 6		X	X		X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[8]2008	(C*, E*, L*, F*) Heavy-Medium Duty	2.5L 4JK1-TC		X	X		X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[7]2007	IF/UC Serie	3.0L 4JJ1-TC						
Euro 5, Euro 4, Euro 3, Euro 2 series	[7]2007	N Series Truck	AT JR405E						
Euro 5, Euro 4, Euro 3, Euro 2 series	[7]2007	N Series Truck	4HG1 (LPG)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[7]2007	N Series Truck	4IG2						
Euro 5, Euro 4, Euro 3, Euro 2 series	[7]2007	N Series Truck	4IG2 (LPG)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[7]2007	N Series Truck	4HJ-TC Bosch						
Euro 5, Euro 4, Euro 3, Euro 2 series	[7]2007	F/G Series Truck	4HL1/4HJ1						
Euro 5, Euro 4, Euro 3, Euro 2 series	[7]2007	F/G Series Truck	4HL1/4HJ1 (Vehicle Interface Module)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[7]2007	F/G Series Truck	4JJ1-TC (C/Rail Tiler3)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[7]2007	F/G Series Truck	4HK1-TC (C/Rail Tiler3)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[7]2007	(C*, E*, L*, F*) Heavy-Medium Duty	6HK1-TC (C/Rail Tiler3)		X	X		X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[7]2007	(C*, E*, L*, F*) Heavy-Medium Duty	6UZ1-TC (C/Rail Tiler3)		X	X		X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[7]2007	(C*, E*, L*, F*) Heavy-Medium Duty	6WG1-TC (C/Rail Tiler3)		X	X		X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[6]2006	(IF/UC) LUV, Rodeo/Frontier, LAO-Rodeo	6WF1-TC (C/Rail)		X	X		X	X
Euro 5, Euro 4, Euro 3, Euro 2 series	[6]2006	(IF/UC) LUV, Rodeo/Frontier, LAO-Rodeo	AT Allsion WT		X	X		X	X
Euro 5, Euro 4, Euro 3, Euro 2 series	[6]2006	(IF/UC) LUV, Rodeo/Frontier, LAO-Rodeo	ESC (with EBS)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[6]2006	(N*) ELF, NPR, NQR, VFR	ABS 6		X	X		X	X
Euro 5, Euro 4, Euro 3, Euro 2 series	[6]2006	(N*) ELF, NPR, NQR, VFR	2.5L 4JK1-TC		X	X		X	X
Euro 5, Euro 4, Euro 3, Euro 2 series	[6]2006	(N*) ELF, NPR, NQR, VFR	3.0L 4JJ1-TC		X	X		X	X
Euro 5, Euro 4, Euro 3, Euro 2 series	[6]2006	(N*) ELF, NPR, NQR, VFR	AT JR405E						
Euro 5, Euro 4, Euro 3, Euro 2 series	[6]2006	(N*) ELF, NPR, NQR, VFR	4HG1 (LPG)		X			X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[6]2006	(N*) ELF, NPR, NQR, VFR	4IG2					X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[6]2006	(Off-Road) Industrial Engine	4IG2 (LPG)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[6]2006	(Off-Road) Industrial Engine	4HJ-TC Bosch						
Euro 5, Euro 4, Euro 3, Euro 2 series	[6]2006	(Off-Road) Industrial Engine	4HL1/4HJ1						
Euro 5, Euro 4, Euro 3, Euro 2 series	[6]2006	(Off-Road) Industrial Engine	4HL1/4HJ1 (Vehicle Interface Module)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[6]2006	(Off-Road) Industrial Engine	4JJ1-TC (C/Rail Tiler3)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[6]2006	(C*, E*, L*, F*) Heavy-Medium Duty	4HK1-TC (C/Rail Tiler3)		X	X		X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[6]2006	(C*, E*, L*, F*) Heavy-Medium Duty	6HK1-TC (C/Rail Tiler3)		X	X		X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[6]2006	(C*, E*, L*, F*) Heavy-Medium Duty	6UZ1-TC (C/Rail Tiler3)		X	X		X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[6]2006	(C*, E*, L*, F*) Heavy-Medium Duty	6WG1-TC (C/Rail Tiler3)		X	X		X	
Euro 5, Euro 4, Euro 3, Euro 2 series	[5]2005	(IF/UC) LUV, Rodeo/Frontier, LAO-Rodeo	6WF1-TC (C/Rail)		X	X		X	X
Euro 5, Euro 4, Euro 3, Euro 2 series	[5]2005	(IF/UC) LUV, Rodeo/Frontier, LAO-Rodeo	AT Allsion WT		X	X		X	X
Euro 5, Euro 4, Euro 3, Euro 2 series	[5]2005	(IF/UC) LUV, Rodeo/Frontier, LAO-Rodeo	ESC (with EBS)						
Euro 5, Euro 4, Euro 3, Euro 2 series	[5]2005	(N*) ELF, NPR, NQR, VFR	ABS 6		X	X		X	X
Euro 5, Euro 4, Euro 3, Euro 2 series	[5]2005	(N*) ELF, NPR, NQR, VFR	2.5L 4JK1-TC		X	X		X	X
Euro 5, Euro 4, Euro 3, Euro 2 series	[5]2005	(N*) ELF, NPR, NQR, VFR	3.0L 4JJ1-TC		X	X		X	X

Region	Series&Year	System	Model	ECU INFO	DTC	DTC Freeze	Data List	Actuals	Spec. Func.
Euro 5, Euro 4, Euro 3, Euro 2 series	from 2000	(C*, E*, L*, F*) Heavy-Medium Duty	6WG1-TC(C/Rail Tiler3)	X	X		X		
Euro 5, Euro 4, Euro 3, Euro 2 series	before 2000	(IF/UC) LUV, Rodeo/Frontier, LAO-Rodeo	6WF1-TC(C/Rail)	X	X		X	X	
Euro 5, Euro 4, Euro 3, Euro 2 series	before 2000	(IF/UC) LUV, Rodeo/Frontier, LAO-Rodeo	AT Allsion WT	X	X		X	X	
Euro 5, Euro 4, Euro 3, Euro 2 series	before 2000	(IF/UC) LUV, Rodeo/Frontier, LAO-Rodeo	ESC(with EBS)						
Euro 5, Euro 4, Euro 3, Euro 2 series	before 2000	(N*) ELF, NPR, NQR, VFR	ABS 6						
Euro 5, Euro 4, Euro 3, Euro 2 series	before 2000	(N*) ELF, NPR, NQR, VFR	EDC 16 BOSCH		X		X	X	
Euro 5, Euro 4, Euro 3, Euro 2 series	before 2000	(N*) ELF, NPR, NQR, VFR	EDC 16 BOSCH	X	X		X	X	
Euro 5, Euro 4, Euro 3, Euro 2 series	before 2000	(N*) ELF, NPR, NQR, VFR	Bosch EDC16C8						
Euro 5, Euro 4, Euro 3, Euro 2 series	before 2000	(N*) ELF, NPR, NQR, VFR	4HL1/4HJ1		X		X		
Euro 5, Euro 4, Euro 3, Euro 2 series	before 2000	(N*) ELF, NPR, NQR, VFR	4HL1/4HJ1(Vehicle Interface Module)				X		
Euro 5, Euro 4, Euro 3, Euro 2 series	before 2000	(Off-Road) Industrial Engine	4TJ1-TC(C/Rail Tiler3)						
Euro 5, Euro 4, Euro 3, Euro 2 series	before 2000	(Off-Road) Industrial Engine	4HK1-TC(C/Rail Tiler3)						
Euro 5, Euro 4, Euro 3, Euro 2 series	before 2000	(Off-Road) Industrial Engine	6HK1-TC(C/Rail Tiler3)						
Euro 5, Euro 4, Euro 3, Euro 2 series	before 2000	(Off-Road) Industrial Engine	6UZ1-TC(C/Rail Tiler3)						
Euro 5, Euro 4, Euro 3, Euro 2 series	before 2000	(Off-Road) Industrial Engine	6WG1-TC(C/Rail Tiler3)						
Euro 5, Euro 4, Euro 3, Euro 2 series	before 2000	(C*, E*, L*, F*) Heavy-Medium Duty	6WF1-TC(C/Rail)	X	X		X		
Euro 5, Euro 4, Euro 3, Euro 2 series	before 2000	(C*, E*, L*, F*) Heavy-Medium Duty	AT Allsion WT		X		X		
Euro 5, Euro 4, Euro 3, Euro 2 series	before 2000	(C*, E*, L*, F*) Heavy-Medium Duty	ESC(with EBS)	X	X		X		
Euro 5, Euro 4, Euro 3, Euro 2 series	before 2000	(C*, E*, L*, F*) Heavy-Medium Duty	ABS 6	X	X		X		
Euro 5, Euro 4, Euro 3, Euro 2 series	ISUZU Light Duty	2.5L 4JK1-TC	EDC 16 BOSCH	X	X		X	X	
Euro 5, Euro 4, Euro 3, Euro 2 series	ISUZU Light Duty	3.0L 4J11-TC	EDC 16 BOSCH	X	X		X	X	
Euro 5, Euro 4, Euro 3, Euro 2 series	ISUZU Light Duty	4JH1-T Denso	Bosch EDC16C8						
Euro 5, Euro 4, Euro 3, Euro 2 series	Engine	6WF1-TC(C/Rail)	EDC 16 BOSCH						
Euro 5, Euro 4, Euro 3, Euro 2 series	Engine	TRANSMISSION	EDC 16 BOSCH						
Euro 5, Euro 4, Euro 3, Euro 2 series	Engine	AT Allsion WT	Bosch EDC16C8						