

MaxiSysCV_Isuzu_Truck_V2.00 Function List (Note:For reference only)

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Year	Vehicle Type	System Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
(F) 2015	Stripped chassis(North	ABS	ABS	●	●	●	●	●	
(F) 2015	Stripped chassis(North America)	Mimamori ECU	Mimamori ECU	●	●	●	●	●	F120 F121 F122 F123 F124 F125 F126 F127
(F) 2015	Stripped chassis(North America)	Diesel exhaust fluid control module	Diesel exhaust fluid control module	●	●	●	●	●	F128 F129 F130 F131 F132 F133 F134 F135
(F) 2015	Stripped chassis(North America)	Engine	3.0L Diesel (4JJ1)	●	●	●	●	●	F136 F137 F138 F139 F140 F141 F142 F143 F144 F146 F147 F148
(F) 2015	Stripped chassis(North America)	FMS CAN converter (if equipped)	FMS CAN converter (if equipped)	●	●	●	●	●	F149
(F) 2015	Stripped chassis(North	Transmission	Transmission	●	●	●	●	●	
(F) 2015	N-series(North America)	ABS	ABS	●	●	●	●	●	
(F) 2015	N-series(North America)	Mimamori ECU	Mimamori ECU	●	●	●	●	●	F121 F122 F123 F124 F125 F126 F127 F128
(F) 2015	N-series(North America)	Diesel exhaust fluid control module	Diesel exhaust fluid control module	●	●	●	●	●	F129 F130 F131 F132 F133 F134 F135 F136
(F) 2015	N-series(North America)	Engine	3.0L Diesel (4JJ1)	●	●	●	●	●	F137 F138 F139 F140 F141 F142 F143 F144 F145 F146 F147 F148 F149
(F) 2015	N-series(North America)	FMS CAN converter (if equipped)	FMS CAN converter (if equipped)	●	●	●	●	●	F150
(F) 2015	N-series(North America)	Transmission	Transmission	●	●	●	●	●	
(F) 2015	N-series(North America)	Engine	6.0L Gas	●	●	●	●	●	F151 F152 F153 F154 F155 F156 F157 F158 F159
(F) 2015	N-series(North America)	Powertrain interface module (PIM)	Powertrain interface module (PIM)	○	●	●	●	○	
(F) 2015	N-series(North America)	Transmission	Transmission	●	●	●	●	●	F160
(F) 2015	N-series(North America)	ABS	ABS	○	●	●	●	●	
(F) 2015	N-series(North America)	Engine	5.2L Diesel (4HK1)	●	●	●	●	●	F136 F137 F138 F139 F140 F141 F142 F143 F144 F145 F146 F147 F148 F158 F161 F162 F163 F164
(F) 2015	N-series(North America)	Diesel exhaust fluid control module	Diesel exhaust fluid control module	●	●	●	●	●	F128 F129 F130 F131 F132 F133 F134 F135
(F) 2015	N-series(North America)	Mimamori ECU	Mimamori ECU	●	●	●	●	●	F120 F121 F122 F123 F124 F125 F126 F127

Year	Vehicle Type	System Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
(F) 2015	N-series(North America)	FMS CAN converter (if equipped)	FMS CAN converter (if equipped)	●	●	●	●	●	F149
(E) 2014	Stripped chassis(North America)	Engine	3.0L Diesel (4JJ1)	●	●	●	●	●	F136 F137 F138 F139 F140 F141 F142 F143 F144 F146 F147 F148
(E) 2014	Stripped chassis(North America)	Diesel exhaust fluid control module	Diesel exhaust fluid control module	●	●	●	●	●	F128 F129 F130 F131 F132 F133 F134 F135
(E) 2014	Stripped chassis(North America)	Transmission	Transmission	●	●	●	●	●	
(E) 2014	Stripped chassis(North America)	ABS	ABS	●	●	●	●	●	
(E) 2014	Stripped chassis(North America)	Mimamori ECU	Mimamori ECU	●	●	●	●	●	F120 F121 F122 F123 F124 F125 F126 F127
(E) 2014	Stripped chassis(North America)	FMS CAN converter (if equipped)	FMS CAN converter (if equipped)	●	●	●	●	●	F149
(E) 2014	N-series(North America)	ABS	ABS	●	●	●	●	●	
(E) 2014	N-series(North America)	Mimamori ECU	Mimamori ECU	●	●	●	●	●	F120 F121 F122 F123 F124 F125 F126 F127
(E) 2014	N-series(North America)	Diesel exhaust fluid control module	Diesel exhaust fluid control module	●	●	●	●	●	F128 F129 F130 F131 F132 F133 F134 F135
(E) 2014	N-series(North America)	Engine	3.0L Diesel (4JJ1)	●	●	●	●	●	F136 F137 F138 F139 F140 F141 F142 F143 F144 F145 F146 F147 F148
(E) 2014	N-series(North America)	FMS CAN converter (if equipped)	FMS CAN converter (if equipped)	●	●	●	●	●	F149
(E) 2014	N-series(North America)	Transmission	Transmission	●	●	●	●	●	
(E) 2014	N-series(North America)	Engine	5.2L Diesel (4HK1)	●	●	●	●	●	F136 F137 F138 F139 F140 F141 F142 F143 F144 F145 F146 F147 F148 F158 F160 F161 F162 F163
(E) 2014	N-series(North America)	ABS	ABS	○	●	●	●	●	
(E) 2014	N-series(North America)	Engine	6.0L Gas	●	●	●	●	●	F150 F151 F152 F153 F154 F155 F156 F157 F158
(E) 2014	N-series(North America)	Powertrain interface module (PIM)	Powertrain interface module (PIM)	○	●	●	●	○	
(E) 2014	N-series(North America)	Transmission	Transmission	●	●	●	●	●	F159
(D) 2013	Stripped chassis(North America)	ABS	ABS	●	●	●	●	●	
(D) 2013	Stripped chassis(North America)	Mimamori ECU	Mimamori ECU	●	●	●	●	●	F120 F122 F123 F124 F125 F126 F127
(D) 2013	Stripped chassis(North America)	Diesel exhaust fluid control module	Diesel exhaust fluid control module	●	●	●	●	●	F128 F129 F130 F131 F132 F133 F134 F135
(D) 2013	Stripped chassis(North America)	Engine	3.0L Diesel (4JJ1)	●	●	●	●	●	F136 F137 F138 F139 F140 F141 F142 F143 F144 F146 F147 F148
(D) 2013	Stripped chassis(North America)	Transmission	Transmission	●	●	●	●	●	

Year	Vehicle Type	System Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
(D) 2013	Stripped chassis(North America)	FMS CAN converter (if equipped)	FMS CAN converter (if equipped)	●	●	●	●	●	F149
(D) 2013	N-series(North America)	ABS	ABS	○	●	●	●	●	
(D) 2013	N-series(North America)	Mimamori ECU	Mimamori ECU	●	●	●	●	●	F120 F122 F123 F124 F125 F126 F127
(D) 2013	N-series(North America)	Diesel exhaust fluid control module	Diesel exhaust fluid control module	●	●	●	●	●	F128 F129 F130 F131 F132 F133 F134 F135
(D) 2013	N-series(North America)	Engine	5.2L Diesel (4HK1)	●	●	●	●	●	F136 F137 F138 F139 F140 F141 F142 F143 F144 F145 F146 F147 F148 F160 F161 F162 F163
(D) 2013	N-series(North America)	Transmission	Transmission	●	●	●	●	●	
(D) 2013	N-series(North America)	ABS	ABS	●	●	●	●	●	
(D) 2013	N-series(North America)	Engine	3.0L Diesel (4JJ1)	●	●	●	●	●	F136 F137 F138 F139 F140 F141 F142 F143 F144 F145 F146 F147 F148
(D) 2013	N-series(North America)	FMS CAN converter (if equipped)	FMS CAN converter (if equipped)	●	●	●	●	●	F149
(D) 2013	N-series(North America)	Engine	6.0L Gas	●	●	●	●	●	F150 F151 F152 F153 F154 F155 F156 F157 F158
(D) 2013	N-series(North America)	Powertrain interface module (PIM)	Powertrain interface module (PIM)	○	●	●	●	○	
(D) 2013	N-series(North America)	Transmission	Transmission	●	●	●	●	●	F159
(C) 2012-(F) 2015	N Series Truck	Engine	4JH1/4KH1	●	●	●	●	●	F36 F63 F71 F118
(C) 2012	Stripped chassis(North America)	ABS	ABS	○	●	●	●	●	
(C) 2012	Stripped chassis(North America)	Mimamori ECU	Mimamori ECU	●	●	●	●	●	F120 F122 F123 F124 F125 F126 F127
(C) 2012	Stripped chassis(North America)	Diesel exhaust fluid control module	Diesel exhaust fluid control module	●	●	●	●	●	F128 F129 F130 F131 F132 F133 F134 F135
(C) 2012	Stripped chassis(North America)	Engine	3.0L Diesel (4JJ1)	●	●	●	●	●	F136 F137 F138 F139 F140 F141 F142 F143 F144 F146 F147 F148
(C) 2012	Stripped chassis(North America)	Transmission	Transmission	●	●	●	●	●	
(C) 2012	N-series(North America)	ABS	ABS	○	●	●	●	●	
(C) 2012	N-series(North America)	Engine	6.0L Gas	●	●	●	●	●	F150 F151 F152 F153 F154 F155 F156 F157
(C) 2012	N-series(North America)	Powertrain interface module (PIM)	Powertrain interface module (PIM)	○	●	●	●	○	
(C) 2012	N-series(North America)	Transmission	Transmission	●	●	●	●	●	F159
(C) 2012	N-series(North America)	Mimamori ECU	Mimamori ECU	●	●	●	●	●	F120 F122 F123 F124 F125 F126 F127
(C) 2012	N-series(North America)	Diesel exhaust fluid control module	Diesel exhaust fluid control module	●	●	●	●	●	F128 F129 F130 F131 F132 F133 F134 F135

Year	Vehicle Type	System Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
(C) 2012	N-series(North America)	Engine	5.2L Diesel (4HK1)	●	●	●	●	●	F136 F137 F138 F139 F140 F141 F142 F143 F144 F145 F146 F147 F148 F160 F161 F162 F163
(C) 2012	N-series(North America)	Transmission	Transmission	●	●	●	●	●	
(C) 2012	N-series(North America)	Engine	3.0L Diesel (4JJ1)	●	●	●	●	●	F136 F137 F138 F139 F140 F141 F142 F143 F144 F145 F146 F147 F148
(B) 2011-(F) 2015	C&E Series Truck	Engine	6UZ1-TC (C/Rail)	●	●	●	●	●	F36 F37 F71 F72 F118
(B) 2011	N-series(North America)	ABS	ABS	○	●	●	●	●	
(B) 2011	N-series(North America)	Engine	5.2L Diesel (4HK1)	●	●	●	●	●	F136 F137 F138 F139 F140 F141 F142 F143 F144 F145 F146 F147 F148 F160 F161 F162 F163
(B) 2011	N-series(North America)	Diesel exhaust fluid control module	Diesel exhaust fluid control module	●	●	●	●	●	F128 F129 F130 F131 F132 F133 F134 F135
(B) 2011	N-series(North America)	Mimamori ECU	Mimamori ECU	●	●	●	●	●	F120 F122 F123 F124 F125 F126 F127
(B) 2011	N-series(North America)	Transmission	Transmission	●	●	●	●	●	
(B) 2011	N-series(North America)	Engine	3.0L Diesel (4JJ1)	●	●	●	●	●	F136 F137 F138 F139 F140 F141 F142 F143 F144 F146 F147 F148
(B) 2011	C&E Series Truck	Engine	6UZ1-TC (C/Rail_NLT)	●	●	●	●	●	F14 F25 F28 F29 F31 F32 F38 F62 F68 F70 F95 F96 F117
(B) 2011	C&E Series Truck	Engine	6WG1-TC (C/Rail_NLT)	●	●	●	●	●	F14 F25 F28 F29 F31 F32 F38 F62 F68 F70 F95 F96 F117
(B) 2011	C&E Series Truck	Engine	6WG1-TC (C/Rail_NLT)	●	●	●	●	●	F14 F25 F27 F30 F38 F62 F68 F70 F94 F117
(A) 2010-(F) 2015	F&G Series Truck	Engine	6UZ1-TC (C/Rail)	●	●	●	●	●	F36 F37 F71 F72 F118
(A) 2010-(F) 2015	C&E Series Truck	Transmission	Smoother-G (AMT)	●	●	●	●	●	F16 F20
(A) 2010	N/W series(North America)	Engine	5.2L Diesel (4HK1)	○	●	●	●	●	F136 F137 F139 F142 F143 F144 F147 F148 F160 F161 F165 F166 F167 F168
(A) 2010	N/W series(North America)	ABS	ABS	○	●	●	●	●	
(A) 2010	N/W series(North America)	Engine	5.2L Diesel (4HK1)	○	●	●	●	●	F136 F137 F139 F142 F143 F144 F147 F148 F160 F161 F164 F165 F166 F167
(A) 2010	N/W series(North America)	Transmission	Transmission	○	●	●	●	●	
(9) 2009-(F) 2015	N Series Truck	Transmission	Smoother (TransTron)	●	●	●	●	○	F118
(9) 2009-(F) 2015	F&G Series Truck	Transmission	Automatic Transmission	●	●	●	●	●	F15 F93
(9) 2009-(E) 2014	F&G Series Truck	Transmission	Smoother (TransTron)	●	●	●	●	○	F118
(9) 2009-(B) 2011	N Series Truck	Engine	4JJ1-TC (C/Rail_Mexico)	○	●	●	●	●	F38 F63 F68 F70 F117
(9) 2009-(B) 2011	F&G Series Truck	Engine	4HK1-TC (C/Rail_NLT)	●	●	●	●	●	F14 F25 F27 F30 F38 F42 F70 F94 F97 F117

Year	Vehicle Type	System Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
(9) 2009-(B) 2011	C&E Series Truck	Engine	6W*1-TC (C/Rail_DLC 3Pin)	●	●	●	●	●	F38 F65 F70 F117
(9) 2009-(A) 2010	C&E Series Truck	Engine	6WG1-TC (C/Rail_NLT)	○	●	●	●	●	F14 F25 F27 F30 F38 F62 F68 F70 F94 F117
(9) 2009	N/W series(North America)	Transmission	Transmission	○	●	●	●	●	
(9) 2009	N/W series(North America)	ABS	ABS	○	●	●	●	●	
(9) 2009	N/W series(North America)	Engine	5.2L Diesel (4HK1)	○	●	●	●	●	F136 F137 F139 F142 F143 F144 F147 F148 F160 F161 F164 F165 F166 F167
(9) 2009	N/W series(North America)	Engine	6.0L Gas	○	●	●	●	●	F150 F151 F152 F153 F154 F155 F156 F157 F193
(9) 2009	N/W series(North America)	Transmission	Transmission	○	●	●	●	●	F159
(9) 2009	N/W series(North America)	Powertrain interface module (PIM)	Powertrain interface module (PIM)	○	●	●	●	○	
(9) 2009	F/T series(North America)	Instrument panel cluster	Instrument panel cluster	●	●	●	●	●	
(9) 2009	F/T series(North America)	Serial data gateway module (if equipped)	Serial data gateway module (if equipped)	●	●	●	○	○	
(9) 2009	F/T series(North America)	Chime module (if equipped)	Chime module (if equipped)	●	●	●	●	○	
(9) 2009	F/T series(North America)	Engine	7.8L Diesel (6HK1)	○	●	●	●	●	F139 F142 F143 F144 F147 F160 F164 F165 F166 F167 F169 F170 F171 F172 F173 F174 F175 F176 F177 F178 F179
(9) 2009	F/T series(North America)	ABS	ABS	●	●	●	●	●	
(9) 2009	F/T series(North America)	Engine	7.8L Diesel (6HK1)	○	●	●	●	●	F139 F142 F143 F144 F147 F160 F164 F165 F166 F167 F168 F169 F170 F171 F172 F173 F174 F175 F177 F178
(9) 2009	F/T series(North America)	Transmission	Transmission	○	●	●	●	●	F180 F181 F182 F183 F184 F185 F186 F187 F188 F189 F190 F191 F192
(9) 2009	C-series(North America)	Engine	7.8L Diesel (6HK1)	○	●	●	●	●	F139 F142 F143 F144 F147 F160 F164 F165 F166 F167 F168 F169 F170 F171 F172 F173 F174 F175 F176 F177 F178
(9) 2009	C-series(North America)	ABS	ABS	●	●	●	●	●	
(9) 2009	C-series(North America)	Instrument panel cluster	Instrument panel cluster	●	●	●	●	●	
(9) 2009	C-series(North America)	Radio	Radio	●	●	●	●	○	
(9) 2009	C-series(North America)	Chime module (if equipped)	Chime module (if equipped)	●	●	●	●	○	
(9) 2009	C-series(North America)	Serial data gateway module (if equipped)	Serial data gateway module (if equipped)	●	●	●	○	○	

Year	Vehicle Type	System Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
(9) 2009	C-series(North America)	Engine	7.8L Diesel (6HK1)	○	●	●	●	●	F139 F142 F143 F144 F147 F160 F164 F165 F166 F167 F168 F169 F170 F171 F172 F173 F174 F175 F177 F178
(9) 2009	C-series(North America)	Transmission	Transmission	○	●	●	●	●	F179 F180 F181 F182 F183 F184 F185 F186 F187 F188 F189 F190 F191
(8) 2008-(F) 2015	TF/UC Series	Engine	2.5L 4JK1-TC (TransTron)	●	●	●	●	●	F36 F63 F71 F118
(8) 2008-(F) 2015	TF/UC Series	Engine	3.0L 4JJ1-TC (TransTron)	●	●	●	●	●	F36 F63 F71 F118
(8) 2008-(F) 2015	TF/UC Series	Body	Immobiliser (Transtron)	●	●	●	●	○	F85
(8) 2008-(F) 2015	N Series Truck	Body	Immobiliser	●	●	●	●	○	F85
(8) 2008-(F) 2015	F&G Series Truck	Engine	4HK1-TC (C/Rail)	●	●	●	●	●	F25 F26 F33 F34 F36 F63 F71 F118
(8) 2008-(F) 2015	F&G Series Truck	Engine	4HK1-TC (C/Rail)	●	●	●	●	●	F25 F26 F34 F36 F52 F63 F71 F118
(8) 2008-(F) 2015	F&G Series Truck	Engine	4HK1-TC (C/Rail)	●	●	●	●	●	F25 F26 F33 F34 F36 F52 F63 F71 F118
(8) 2008-(F) 2015	F&G Series Truck	Engine	4HK1-TC (C/Rail)	●	●	●	●	●	F36 F63 F71 F118
(8) 2008-(B) 2011	N Series Truck	Engine	4HK1/4JJ1 (C/Rail_Euro2)	●	●	●	●	●	F38 F63 F68 F70 F117
(8) 2008-(B) 2011	N Series Truck	Engine	4HK1/4JJ1 (C/Rail_Euro3)	●	●	●	●	●	F38 F63 F68 F70 F117
(8) 2008-(B) 2011	N Series Truck	Body	Body control module	●	●	●	●	●	F1 F2 F3 F10 F41 F43 F44 F45 F46 F53 F58 F60 F102 F103 F104 F105 F108 F111 F118
(8) 2008-(B) 2011	F&G Series Truck	Engine	4HK1/6HK1 (C/Rail_Euro2)	●	●	●	●	●	F38 F62 F68 F70 F97 F117
(8) 2008-(B) 2011	F&G Series Truck	Engine	4HK1/6HK1 (C/Rail_Euro3)	●	●	●	●	●	F38 F62 F68 F70 F97 F117
(8) 2008-(B) 2011	F&G Series Truck	Engine	6UZ1-TC (C/Rail_Euro3)	●	●	●	○	●	F38 F62 F70 F117
(8) 2008-(B) 2011	F&G Series Truck	Engine	6UZ1-TC (C/Rail_Euro3)	●	●	●	○	●	F38 F62 F68 F70 F117
(8) 2008-(B) 2011	F&G Series Truck	Engine	6UZ1-TC (C/Rail_NLT)	●	●	●	●	●	F14 F25 F27 F30 F38 F62 F68 F70 F94 F97 F117
(8) 2008-(B) 2011	F&G Series Truck	Body	Body control module	○	●	●	●	●	F6 F7 F8 F9 F51 F61 F66 F89 F90 F101 F110 F118
(8) 2008-(B) 2011	F&G Series Truck	Body	Body control module	●	●	●	●	●	F1 F2 F3 F10 F41 F43 F44 F45 F46 F53 F58 F60 F102 F103 F104 F105 F108 F111 F118
(8) 2008-(B) 2011	C&E Series Truck	Chassis	Millimeterwave Radar Cruise	●	○	○	●	○	F4 F5 F73 F79 F80 F91 F92 F119
(8) 2008	N/W series(North America)	Engine	6.0L Gas	○	●	●	●	●	F150 F151 F152 F153 F154 F155 F156 F157 F192
(8) 2008	N/W series(North America)	Transmission	Transmission	○	●	●	●	●	F159
(8) 2008	N/W series(North America)	ABS	ABS	○	●	●	●	●	

Year	Vehicle Type	System Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
(8) 2008	N/W series(North America)	Powertrain interface module (PIM)	Powertrain interface module (PIM)	○	●	●	●	○	
(8) 2008	N/W series(North America)	Engine	5.2L Diesel (4HK1)	○	●	●	●	●	F136 F137 F139 F142 F143 F144 F147 F148 F160 F161 F164 F165 F166 F167
(8) 2008	N/W series(North America)	Transmission	Transmission	○	●	●	●	●	
(8) 2008	N Series Truck	Transmission	Smoother / Smoother-Ex	●	●	●	●	○	F81 F87
(8) 2008	F/T series(North America)	ABS	ABS	●	●	●	●	●	
(8) 2008	F/T series(North America)	Instrument panel cluster	Instrument panel cluster	●	●	●	●	●	
(8) 2008	F/T series(North America)	Chime module (if equipped)	Chime module (if equipped)	●	●	●	●	○	
(8) 2008	F/T series(North America)	Serial data gateway module (if equipped)	Serial data gateway module (if equipped)	●	●	●	○	○	
(8) 2008	F/T series(North America)	Engine	7.8L Diesel (6HK1)	○	●	●	●	●	F139 F142 F143 F144 F147 F160 F164 F165 F166 F167 F168 F169 F170 F171 F172 F174 F175 F177 F178
(8) 2008	F/T series(North America)	Transmission	Transmission	○	●	●	●	●	F179 F180 F181 F182 F183 F184 F185 F186 F187 F188 F189 F190 F191
(8) 2008	F/T series(North America)	Engine	7.8L Diesel (6HK1)	○	●	●	●	●	F139 F142 F143 F144 F147 F160 F164 F165 F166 F167 F168 F169 F170 F171 F172 F174 F175 F176 F177 F178
(8) 2008	C-series(North America)	Engine	7.8L Diesel (6HK1)	○	●	●	●	●	F139 F142 F143 F144 F147 F160 F164 F165 F166 F167 F168 F169 F170 F171 F172 F174 F175 F177 F178
(8) 2008	C-series(North America)	Transmission	Transmission	○	●	●	●	●	F179 F180 F181 F182 F183 F184 F185 F186 F187 F188 F189 F190 F191
(8) 2008	C-series(North America)	ABS	ABS	●	●	●	●	●	
(8) 2008	C-series(North America)	Instrument panel cluster	Instrument panel cluster	●	●	●	●	●	
(8) 2008	C-series(North America)	Radio	Radio	●	●	●	●	○	
(8) 2008	C-series(North America)	Chime module (if equipped)	Chime module (if equipped)	●	●	●	●	○	
(8) 2008	C-series(North America)	Serial data gateway module (if equipped)	Serial data gateway module (if equipped)	●	●	●	○	○	
(8) 2008	C-series(North America)	Engine	7.8L Diesel (6HK1)	○	●	●	●	●	F139 F142 F143 F144 F147 F160 F164 F165 F166 F167 F168 F169 F170 F171 F172 F174 F175 F176 F177 F178
(8) 2008	C&E Series Truck	Information System	MIMAMORI	●	●	●	●	○	F12 F17 F19 F23 F39 F59 F82 F112 F113 F115

Year	Vehicle Type	System Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
(7) 2007-(F) 2015	TF/UC Series	Engine	2.5L 4JK1-TC (Delphi)	●	●	●	●	●	F36 F63 F71 F118
(7) 2007-(F) 2015	TF/UC Series	Engine	3.0L 4JJ1-TC (Delphi)	●	●	●	●	●	F36 F63 F71 F118
(7) 2007-(F) 2015	TF/UC Series	Transmission	AT JR405E	●	●	●	●	●	F76 F86
(7) 2007-(F) 2015	TF/UC Series	Transmission	AW30-40LE	●	●	●	●	●	F118
(7) 2007-(F) 2015	TF/UC Series	Chassis	ABS	●	●	●	●	●	
(7) 2007-(F) 2015	TF/UC Series	Body	Airbag	●	●	●	●	○	
(7) 2007-(F) 2015	TF/UC Series	Body	Immobiliser (2.4L LG1	●	●	●	●	○	
(7) 2007-(F) 2015	TF/UC Series	Body	Immobiliser (Delphi)	●	●	●	●	○	F85
(7) 2007-(F) 2015	TF/UC Series	Body	Immobiliser (V6 Engine)	●	●	●	●	○	F85
(7) 2007-(F) 2015	N Series Truck	Engine	4HK1-TC (C/Rail)	●	●	●	●	●	F25 F26 F33 F34 F36 F63 F71 F118
(7) 2007-(F) 2015	N Series Truck	Engine	4HK1-TC (C/Rail)	●	●	●	●	●	F25 F26 F34 F36 F52 F63 F71 F118
(7) 2007-(F) 2015	N Series Truck	Engine	4HK1-TC (C/Rail)	●	●	●	●	●	F25 F26 F33 F34 F36 F52 F63 F71 F118
(7) 2007-(F) 2015	N Series Truck	Engine	4HK1-TC (C/Rail)	●	●	●	●	●	F36 F63 F71 F118
(7) 2007-(F) 2015	N Series Truck	Engine	4JJ1-TC (C/Rail)	●	●	●	●	●	F25 F26 F33 F34 F36 F63 F71 F118
(7) 2007-(F) 2015	N Series Truck	Engine	4JJ1-TC (C/Rail)	●	●	●	●	●	F25 F26 F33 F34 F36 F52 F63 F71 F118
(7) 2007-(F) 2015	N Series Truck	Engine	4JJ1-TC (C/Rail)	●	●	●	●	●	F36 F63 F71 F118
(7) 2007-(F) 2015	F&G Series Truck	Engine	6HK1-TC (C/Rail)	●	●	●	●	●	F25 F26 F33 F34 F36 F37 F52 F63 F71 F72 F118
(7) 2007-(F) 2015	F&G Series Truck	Engine	6HK1-TC (C/Rail)	●	●	●	●	●	F25 F26 F33 F34 F36 F37 F63 F71 F72 F118
(7) 2007-(F) 2015	F&G Series Truck	Engine	6HK1-TC (C/Rail)	●	●	●	●	●	F36 F37 F63 F71 F72 F118
(7) 2007-(F) 2015	F&G Series Truck	Body	Immobiliser	●	●	●	●	○	F85
(7) 2007-(F) 2015	C&E Series Truck	Engine	6WG1-TC (C/Rail)	●	●	●	●	●	F25 F36 F37 F71 F72 F118
(7) 2007-(F) 2015	C&E Series Truck	Engine	6WG1-TC (C/Rail)	●	●	●	●	●	F36 F37 F71 F72 F118
(7) 2007-(B) 2011	TF/UC Series	Engine	2. XL L4 HV240	●	●	●	●	●	
(7) 2007-(B) 2011	TF/UC Series	Engine	3.5L V6 6VE1 Hitachi	○	●	●	●	●	
(7) 2007-(B) 2011	TF/UC Series	Engine	4JA1-TC Bosch	●	●	●	●	●	F76 F85
(7) 2007-(B) 2011	TF/UC Series	Engine	4JH1-TC Bosch	●	●	●	●	●	F76 F85
(7) 2007-(B) 2011	TF/UC Series	Transmission	AT JR405E	●	●	●	●	●	F76 F85
(7) 2007-(B) 2011	TF/UC Series	Transmission	AW30-40LE	●	●	●	●	●	F76 F85
(7) 2007-(B) 2011	TF/UC Series	Chassis	ABS	●	●	●	●	●	
(7) 2007-(B) 2011	TF/UC Series	Chassis	ABS 8	●	●	●	●	●	
(7) 2007-(B) 2011	TF/UC Series	Body	Airbag	●	●	●	●	○	
(7) 2007-(B) 2011	TF/UC Series	Body	Airbag SIEMENS	●	●	●	●	○	
(7) 2007-(B) 2011	TF/UC Series	Body	Immobiliser	●	●	●	●	○	F54

Year	Vehicle Type	System Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
(7) 2007-(B) 2011	N Series Truck	Engine	4HK1-TC (C/Rail_NLT)	●	●	●	●	●	F14 F25 F27 F30 F38 F42 F68 F70 F94 F97 F117
(7) 2007-(B) 2011	N Series Truck	Engine	4HV1 (CNG)	●	●	●	●	●	F21
(7) 2007-(B) 2011	N Series Truck	Engine	4JH1-TC Bosch	●	●	●	●	●	F85
(7) 2007-(B) 2011	N Series Truck	Engine	4JH1-TC Bosch	●	●	●	●	●	F76 F85
(7) 2007-(B) 2011	N Series Truck	Engine	4JJ1-TC (C/Rail_NLT)	●	●	●	●	●	F14 F25 F27 F30 F38 F42 F68 F70 F94 F97 F117
(7) 2007-(B) 2011	N Series Truck	Engine	Hybrid System	●	●	●	●	●	F87
(7) 2007-(B) 2011	N Series Truck	Engine	Hybrid System	●	●	●	●	●	F75 F87
(7) 2007-(B) 2011	N Series Truck	Engine	IDLING STOP (BCM)	●	○	○	●	○	F116
(7) 2007-(B) 2011	N Series Truck	Transmission	AT A460	●	●	●	●	●	
(7) 2007-(B) 2011	N Series Truck	Transmission	Smoother / Smoother-Ex	●	●	●	●	○	F81 F83 F84 F87
(7) 2007-(B) 2011	N Series Truck	Chassis	ABS/ASR	●	●	●	●	●	
(7) 2007-(B) 2011	N Series Truck	Body	Airbag SRS	●	○	○	●	○	
(7) 2007-(B) 2011	N Series Truck	Body	Body control module	○	●	●	●	●	F6 F7 F8 F9 F51 F66 F89 F90 F101 F110 F118
(7) 2007-(B) 2011	N Series Truck	Body	Body control module	○	●	●	●	●	F6 F7 F8 F9 F51 F61 F66 F89 F90 F101 F110 F118
(7) 2007-(B) 2011	N Series Truck	Body	Body control module	●	●	●	●	●	F6 F7 F8 F9 F51 F61 F66 F89 F90 F110 F118
(7) 2007-(B) 2011	N Series Truck	Body	Body control module	●	●	●	●	●	F6 F7 F8 F9 F51 F61 F66 F89 F90 F101 F110 F118
(7) 2007-(B) 2011	N Series Truck	Body	Immobiliser	●	●	●	●	○	F54
(7) 2007-(B) 2011	N Series Truck	Information System	MIMAMORI	●	●	●	●	○	F35 F40 F41 F47 F55 F57 F77 F78 F106 F112 F113 F116
(7) 2007-(B) 2011	N Series Truck	Information System	MIMAMORI	●	●	●	●	○	F41 F47 F55 F57 F77 F78 F106 F112 F115 F116
(7) 2007-(B) 2011	N Series Truck	Information System	MIMAMORI	●	●	●	●	○	F35 F40 F41 F47 F55 F56 F57 F67 F77 F78 F106 F112 F115 F116
(7) 2007-(B) 2011	F&G Series Truck	Engine	4HK1-TC (C/Rail_NLT)	●	●	●	●	●	F14 F25 F27 F30 F38 F42 F68 F70 F94 F97 F117
(7) 2007-(B) 2011	F&G Series Truck	Engine	6HF1-TC (CNG)	○	○	○	●	○	F21
(7) 2007-(B) 2011	F&G Series Truck	Engine	6HK1-TC (C/Rail_NLT)	●	●	●	●	●	F14 F25 F27 F30 F38 F42 F62 F68 F70 F94 F97 F117
(7) 2007-(B) 2011	F&G Series Truck	Engine	IDLING STOP (BCM)	●	○	○	●	○	F116
(7) 2007-(B) 2011	F&G Series Truck	Transmission	Smoother / Smoother-Fx	●	●	●	●	○	F81 F88 F115
(7) 2007-(B) 2011	F&G Series Truck	Chassis	ABS 6	●	●	●	●	●	
(7) 2007-(B) 2011	F&G Series Truck	Chassis	ABS/ASR ADVICS	●	●	●	●	●	
(7) 2007-(B) 2011	F&G Series Truck	Chassis	Air Suspension	●	●	●	●	●	F22
(7) 2007-(B) 2011	F&G Series Truck	Body	Airbag SRS	●	○	○	●	○	

Year	Vehicle Type	System Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
(7) 2007-(B) 2011	F&G Series Truck	Body	Body control module	●	●	●	●	●	F6 F7 F8 F9 F51 F66 F89 F90 F101 F110 F118
(7) 2007-(B) 2011	F&G Series Truck	Body	Body control module	●	●	●	●	●	F6 F7 F8 F9 F51 F61 F66 F89 F90 F101 F110 F118
(7) 2007-(B) 2011	F&G Series Truck	Body	Immobiliser	●	●	●	●	○	F54
(7) 2007-(B) 2011	F&G Series Truck	Information System	MIMAMORI	●	●	●	●	○	F35 F40 F41 F47 F55 F57 F77 F78 F106 F112 F113 F115 F116
(7) 2007-(B) 2011	F&G Series Truck	Information System	MIMAMORI	●	●	●	●	○	F41 F47 F55 F57 F77 F78 F106 F112 F115 F116
(7) 2007-(B) 2011	F&G Series Truck	Information System	Speedometer Control Device	●	○	○	●	○	
(7) 2007-(B) 2011	C&E Series Truck	Engine	6UZ1-TC (C/Rail_NLT)	●	●	●	●	●	F14 F25 F27 F30 F38 F62 F68 F70 F94 F117
(7) 2007-(B) 2011	C&E Series Truck	Engine	6W*1-TC (C/Rail_DLC 3Pin)	●	●	●	●	●	F38 F65 F68 F70 F117
(7) 2007-(B) 2011	C&E Series Truck	Engine	6WG1-TC (C/Rail_NST)	●	●	●	●	●	F38 F65 F68 F70 F117
(7) 2007-(B) 2011	C&E Series Truck	Chassis	ABS 6	●	●	●	●	●	
(7) 2007-(B) 2011	C&E Series Truck	Chassis	ABS/IESC	●	●	●	●	●	F74
(7) 2007-(B) 2011	C&E Series Truck	Chassis	Air Suspension	●	●	●	●	●	F22
(7) 2007-(B) 2011	C&E Series Truck	Chassis	EBS	●	●	●	●	●	F48
(7) 2007-(B) 2011	C&E Series Truck	Chassis	ESC(with EBS)	●	●	●	●	●	
(7) 2007-(B) 2011	C&E Series Truck	Chassis	Hydraulic Retarder	●	●	●	●	○	
(7) 2007-(B) 2011	C&E Series Truck	Body	Driving Safety Adviser	●	●	●	●	●	
(7) 2007-(B) 2011	C&E Series Truck	Information System	MIMAMORI	●	●	●	●	○	F12 F13 F17 F23 F39 F49 F59 F82 F112 F113
(7) 2007-(A) 2010	(Off-Road) Industrial Engine	Engine	4HK1-TC (C/Rail_Tier3)	●	●	●	●	●	F38 F68 F70 F117
(7) 2007-(A) 2010	(Off-Road) Industrial Engine	Engine	4JJ1-TC (C/Rail_Tier3)	●	●	●	●	●	F38 F68 F70 F117
(7) 2007-(8) 2008	KV/KR Bus Series	Engine	6HK1-TC (C/Rail)	●	●	●	●	●	F27 F30 F38 F62 F68 F70 F94 F97 F117
(7) 2007-(8) 2008	F&G Series Truck	Transmission	Automatic Transmission	●	●	●	●	●	F15 F93
(7) 2007-(8) 2008	C&E Series Truck	Engine	6WG1-TC (C/Rail_NLT)	●	●	●	●	●	F14 F25 F27 F30 F38 F62 F68 F70 F94 F117
(7) 2007	N/W series(North America)	ABS	ABS	○	●	●	●	●	
(7) 2007	N/W series(North America)	Engine	5.2L Diesel (4HK1)	○	●	●	●	●	F142 F143 F144 F147 F160 F164 F165 F166 F167 F169 F172
(7) 2007	N/W series(North America)	Transmission	Transmission	○	●	●	●	●	
(7) 2007	N/W series(North America)	Engine	5.2L Diesel (4HK1)	○	●	●	●	●	F136 F137 F139 F142 F143 F144 F147 F148 F160 F161 F164 F165 F166 F167
(7) 2007	N/W series(North America)	Engine	6.0L Gas	○	●	●	●	●	F152 F153 F155
(7) 2007	N Series Truck	Transmission	Smoother / Smoother-Ex	●	●	●	●	○	F81 F87
(7) 2007	KV/KR Bus Series	Engine	6HF1-TC (CNG)	○	○	○	●	○	F21

Year	Vehicle Type	System Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
(7) 2007	H/C series (North America)	Engine	7.8L Diesel (6HK1)	○	●	●	●	●	F142 F143 F144 F147 F164 F165 F166 F167 F168 F172 F174 F175 F176 F178
(7) 2007	H/C series (North America)	ABS	ABS	●	●	●	●	●	
(7) 2007	H/C series (North America)	Transmission	Transmission	○	●	●	●	●	F179 F180 F181 F182 F183 F184 F185 F186 F187 F188 F189 F190 F191
(7) 2007	H/C series (North America)	Chime module (if equipped)	Chime module (if equipped)	●	●	●	●	○	
(7) 2007	H/C series (North America)	Instrument panel cluster	Instrument panel cluster	●	●	●	●	●	
(7) 2007	H/C series (North America)	Radio	Radio	●	●	●	●	○	
(7) 2007	H/C series (North America)	Serial data gateway module (if equipped)	Serial data gateway module (if equipped)	●	●	●	○	○	
(7) 2007	F/T series (North America)	Engine	7.8L Diesel (6HK1)	○	●	●	●	●	F142 F143 F144 F147 F164 F165 F166 F167 F168 F172 F174 F175 F176 F178
(7) 2007	F/T series (North America)	ABS	ABS	●	●	●	●	●	
(7) 2007	F/T series (North America)	Transmission	Transmission	○	●	●	●	●	F179 F180 F181 F182 F183 F184 F185 F186 F187 F188 F189 F190 F191
(7) 2007	F/T series (North America)	Instrument panel cluster	Instrument panel cluster	●	●	●	●	●	
(7) 2007	F/T series (North America)	Chime module (if equipped)	Chime module (if equipped)	●	●	●	●	○	
(7) 2007	F/T series (North America)	Serial data gateway module (if equipped)	Serial data gateway module (if equipped)	●	●	●	○	○	
(7) 2007	C&E Series Truck	Chassis	Millimeterwave Radar	●	●	●	●	●	F5 F80 F91
(6) 2006-(F) 2015	TF/UC Series	Engine	2.4L LG1 Euro3	●	●	●	●	●	F69 F86 F98 F109
(6) 2006-(F) 2015	TF/UC Series	Engine	V6 Engine	●	●	●	●	●	F64 F107
(6) 2006-(F) 2015	TF/UC Series	Engine	V6 Engine	●	●	●	●	●	F64 F69 F107
(6) 2006-(F) 2015	TF/UC Series	Transmission	Automatic Transmission	●	●	●	●	●	F100
(6) 2006-(F) 2015	TF/UC Series	Body	Powertrain interface	●	●	●	●	●	F85
(6) 2006	TF/UC Series	Chassis	ABS	○	●	●	●	●	
(6) 2006	TF/UC Series	Body	Airbag	○	●	●	●	○	
(6) 2006	TF/UC Series	Body	Immobiliser	●	●	●	●	○	
(6) 2006	N/W series (North America)	Transmission	Transmission	○	●	●	●	●	
(6) 2006	N/W series (North America)	Engine	5.2L Diesel (4HK1)	○	●	●	●	●	F160 F169
(6) 2006	N/W series (North America)	ABS	ABS	○	●	●	●	●	
(6) 2006	N/W series (North America)	Engine	5.2L Diesel (4HK1)	○	●	●	●	●	F142 F143 F144 F147 F160 F164 F165 F166 F167 F169 F172
(6) 2006	N/W series (North America)	Engine	6.0L Gas	○	●	●	●	●	F152 F153 F155

Year	Vehicle Type	System Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
(6) 2006	H/C series (North America)	Engine	7.8L Diesel (6HK1)	○	●	●	●	●	F142 F143 F144 F147 F164 F165 F166 F167 F168 F172 F174 F175 F176 F178
(6) 2006	H/C series (North America)	Transmission	Transmission	○	●	●	●	●	F179 F180 F181 F182 F183 F184 F185 F186 F187 F188 F191
(6) 2006	H/C series (North America)	ABS	ABS	●	●	●	●	●	
(6) 2006	H/C series (North America)	Chime module (if equipped)	Chime module (if equipped)	●	●	●	●	○	
(6) 2006	H/C series (North America)	Instrument panel cluster	Instrument panel cluster	●	●	●	●	●	
(6) 2006	H/C series (North America)	Radio	Radio	●	●	●	●	○	
(6) 2006	H/C series (North America)	Serial data gateway module (if equipped)	Serial data gateway module (if equipped)	●	●	●	○	○	
(6) 2006	F/T series (North America)	Engine	7.8L Diesel (6HK1)	○	●	●	●	●	F142 F143 F144 F147 F164 F165 F166 F167 F168 F172 F174 F175 F176 F178
(6) 2006	F/T series (North America)	ABS	ABS	●	●	●	●	●	
(6) 2006	F/T series (North America)	Instrument panel cluster	Instrument panel cluster	●	●	●	●	●	
(6) 2006	F/T series (North America)	Chime module (if equipped)	Chime module (if equipped)	●	●	●	●	○	
(6) 2006	F/T series (North America)	Serial data gateway module (if equipped)	Serial data gateway module (if equipped)	●	●	●	○	○	
(6) 2006	F/T series (North America)	Transmission	Transmission	○	●	●	●	●	F179 F180 F181 F182 F183 F184 F185 F186 F187 F188 F191
(6) 2006	(TF/UC) LUV, Rodeo/Frontier, LAO-Rodeo	Engine	2.5L 4JK1-TC	○	●	●	●	●	F38 F68 F70 F76 F117
(6) 2006	(N*) ELF, NPR, NQR, VFR	Engine	MIMAMORI	●	●	●	●	○	F12 F17 F23 F39 F59 F82 F112 F113 F114
(6) 2006	(N*) ELF, NPR, NQR, VFR	Transmission	Smoother / Smoother-E Auto Shift	●	●	●	●	○	F81 F87
(6) 2006	(C*, E*, L*, F*) Heavy, Medium Duty	Engine	6UZ1-TC (C/Rail)	●	●	●	●	●	F14 F25 F27 F30 F38 F62 F68 F70 F94 F117
(6) 2006	(C*, E*, L*, F*) Heavy, Medium Duty	Engine	6UZ1-TC (C/Rail)	●	●	●	●	●	F25 F27 F30 F38 F68 F70 F94 F117
(6) 2006	(C*, E*, L*, F*) Heavy, Medium	Chassis	Air Suspension(Export)	●	●	●	●	●	F22
(6) 2006	(C*, E*, L*, F*) Heavy, Medium	Chassis	EBS	●	●	●	●	●	F48
(5) 2005-(A) 2010	(Off-Road) Industrial Engine	Engine	4HK1-TC (C/Rail_Tier3)	●	●	●	●	●	F38 F68 F70 F117
(5) 2005-(A) 2010	(Off-Road) Industrial Engine	Engine	4JJ1-TC (C/Rail_Tier3)	●	●	●	●	●	F38 F68 F70 F117
(5) 2005-(A) 2010	(Off-Road) Industrial Engine	Engine	6HK1-TC (C/Rail_Tier3)	●	●	●	●	●	F38 F68 F70 F117
(5) 2005-(A) 2010	(Off-Road) Industrial Engine	Engine	6UZ1-TC (C/Rail_Tier3)	●	●	●	●	●	F38 F68 F70 F117
(5) 2005-(A) 2010	(Off-Road) Industrial Engine	Engine	6WG1-TC (C/Rail_Tier3)	●	●	●	●	●	F38 F68 F70 F117
(5) 2005-(8) 2008	KV/KR Bus Series	Chassis	ABS 6	●	●	●	●	●	

Year	Vehicle Type	System Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
(5) 2005- (6) 2006	KV/KR Bus Series	Engine	6HK1-TC (C/Rail)	○	○	○	●	○	F68 F70 F87
(5) 2005- (6) 2006	(TF/UC) LUV, Rodeo/Frontier, LAO-Rodeo	Engine	2.5L 4JK1-TC	○	●	●	●	●	F38 F68 F70 F117
(5) 2005- (6) 2006	(TF/UC) LUV, Rodeo/Frontier, LAO-Rodeo	Engine	2.5L 4JK1-TC	●	●	●	●	●	F38 F68 F70 F117
(5) 2005- (6) 2006	(TF/UC) LUV, Rodeo/Frontier, LAO-Rodeo	Engine	3.0L 4JJ1-TC	○	●	●	●	●	F38 F68 F70 F76 F117
(5) 2005- (6) 2006	(TF/UC) LUV, Rodeo/Frontier, LAO-Rodeo	Engine	3.0L 4JJ1-TC	○	●	●	●	●	F38 F38 F68 F70 F117 F117
(5) 2005- (6) 2006	(N*) ELF, NPR, NQR, VFR	Engine	4HK1-TC (C/Rail)	●	●	●	●	●	F25 F27 F30 F38 F68 F70 F94 F117
(5) 2005- (6) 2006	(N*) ELF, NPR, NQR, VFR	Engine	4HV1 (CNG)	●	●	●	●	●	F21
(5) 2005- (6) 2006	(N*) ELF, NPR, NQR, VFR	Engine	MIMAMORI	●	●	●	●	○	F12 F17 F23 F39 F59 F82 F112 F113 F114 F115
(5) 2005- (6) 2006	(C*, E*, L*, F*) Heavy, Medium Duty	Engine	4HK1-TC (C/Rail)	●	●	●	●	●	F25 F27 F30 F38 F68 F70 F94 F117
(5) 2005- (6) 2006	(C*, E*, L*, F*) Heavy, Medium	Engine	6UZ1-TC (C/Rail)	●	●	●	●	●	F38 F68 F70 F117
(5) 2005- (6) 2006	(C*, E*, L*, F*) Heavy, Medium	Engine	6WF1-TC (C/Rail)	●	●	●	●	●	F38 F65 F68 F70 F117
(5) 2005- (6) 2006	(C*, E*, L*, F*) Heavy, Medium	Engine	6WG1-TC (C/Rail)	●	●	●	●	●	F38 F65 F68 F70 F117
(5) 2005- (6) 2006	(C*, E*, L*, F*) Heavy, Medium Duty	Engine	MIMAMORI	●	●	●	●	○	F12 F17 F18 F19 F23 F39 F59 F82 F112 F113 F115
(5) 2005- (6) 2006	(C*, E*, L*, F*) Heavy, Medium Duty	Engine	MIMAMORI (F**)	●	●	●	●	○	F12 F17 F23 F39 F59 F82 F112 F113 F115
(5) 2005- (6) 2006	(C*, E*, L*, F*) Heavy, Medium	Transmission	Smoother-F Auto Shift	●	●	●	●	○	F81 F88 F115
(5) 2005- (6) 2006	(C*, E*, L*, F*) Heavy, Medium	Chassis	ABS 6	●	●	●	●	●	
(5) 2005- (6) 2006	(C*, E*, L*, F*) Heavy, Medium	Chassis	ESC(with EBS)	●	●	●	●	●	
(5) 2005- (6) 2006	(C*, E*, L*, F*) Heavy, Medium	Body	Driving Safety Adviser	●	●	●	●	●	
(5) 2005	N/W series(North America)	ABS	ABS	○	●	●	●	●	
(5) 2005	N/W series(North America)	Transmission	Transmission	○	●	●	●	●	
(5) 2005	N/W series(North America)	Engine	6.0L Gas	○	●	●	●	●	F152 F153 F155
(5) 2005	N/W series(North America)	Engine	5.2L Diesel	○	●	●	●	●	F142 F143 F144 F147 F164 F165 F166 F167 F169 F172
(5) 2005	H/C series(North America)	Engine	7.8L Diesel	○	●	●	●	●	F142 F143 F144 F147 F164 F165 F166 F167 F168 F172 F174 F175 F176 F178
(5) 2005	H/C series(North America)	Transmission	Transmission	○	●	●	●	●	F179 F180 F181 F182 F183 F184 F185 F186 F187 F188 F191
(5) 2005	H/C series(North America)	ABS	ABS	●	●	●	●	●	
(5) 2005	H/C series(North America)	Chime module (if equipped)	Chime module (if equipped)	●	●	●	●	○	
(5) 2005	H/C series(North America)	Instrument panel cluster	Instrument panel cluster	●	●	●	●	●	
(5) 2005	H/C series(North America)	Radio	Radio	●	●	●	●	○	

Year	Vehicle Type	System Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
(5) 2005	H/C series(North America)	Serial data gateway module (if equipped)	Serial data gateway module (if equipped)	●	●	●	○	○	
(5) 2005	F/T series(North America)	Engine	7.8L Diesel	○	●	●	●	●	F142 F143 F144 F147 F164 F165 F166 F167 F168 F172 F174 F175 F176 F178
(5) 2005	F/T series(North America)	Transmission	Transmission	○	●	●	●	●	F179 F180 F181 F182 F183 F184 F185 F186 F187 F188 F191
(5) 2005	F/T series(North America)	ABS	ABS	●	●	●	●	●	
(5) 2005	F/T series(North America)	Instrument panel cluster	Instrument panel cluster	●	●	●	●	●	
(5) 2005	F/T series(North America)	Chime module (if equipped)	Chime module (if equipped)	●	●	●	●	○	
(5) 2005	F/T series(North America)	Serial data gateway module (if equipped)	Serial data gateway module (if equipped)	●	●	●	○	○	
(5) 2005	(C*, E*, L*, F*) Heavy, Medium	Engine	6WF1-TC (C/Rail)	●	●	●	●	●	F65 F68 F70
(4) 2004-(6) 2006	(N*) ELF, NPR, NQR, VFR	Engine	4HG1(LPG)	●	●	●	●	●	
(4) 2004-(6) 2006	(N*) ELF, NPR, NQR, VFR	Engine	4HL1-NA (C/Rail)	○	○	○	●	○	F25 F27 F38 F70 F94 F117
(4) 2004-(6) 2006	(N*) ELF, NPR, NQR, VFR	Engine	4HL1-TC (C/Rail)	○	○	○	●	○	F38 F70 F117
(4) 2004-(6) 2006	(N*) ELF, NPR, NQR, VFR	Engine	4JG2(LPG)	●	●	●	●	●	
(4) 2004-(6) 2006	(N*) ELF, NPR, NQR, VFR	Engine	Hybrid System	●	●	●	●	●	F87
(4) 2004-(6) 2006	(N*) ELF, NPR, NQR, VFR	Transmission	Smoother / Smoother-E Auto Shift	●	●	●	●	○	F81 F87
(4) 2004-(6) 2006	(N*) ELF, NPR, NQR, VFR	Transmission	Smoother-E	○	○	○	●	○	F81 F87
(4) 2004-(6) 2006	(C*, E*, L*, F*) Heavy, Medium	Engine	6HK1-TC (C/Rail)	○	○	○	●	○	F38 F68 F70 F117
(4) 2004-(6) 2006	(C*, E*, L*, F*) Heavy, Medium Duty	Engine	6HL1-NA (C/Rail)	○	○	○	●	○	F25 F27 F38 F68 F70 F94 F117
(4) 2004-(6) 2006	(C*, E*, L*, F*) Heavy, Medium	Chassis	ABS/ASR ADVICS	●	●	●	●	●	
(4) 2004-(5) 2005	(N*) ELF, NPR, NQR, VFR	Engine	MIMAMORI	●	●	●	●	○	F11 F12 F23 F39 F82 F112 F113 F114 F115
(4) 2004-(5) 2005	(C*, E*, L*, F*) Heavy, Medium Duty	Engine	MIMAMORI (F**)	●	●	●	●	○	F12 F17 F23 F39 F82 F112 F113 F114 F115
(4) 2004	N/W series(North America)	ABS	ABS	○	●	●	●	●	
(4) 2004	N/W series(North America)	Engine	6.0L Gas	○	●	●	●	●	F152 F153 F154 F155
(4) 2004	N/W series(North America)	Transmission	Transmission	○	●	●	●	●	
(4) 2004	FRR/WT5500(North America)	Transmission	Transmission	○	●	●	●	●	
(4) 2004	F/T series(North America)	Transmission	Transmission	○	●	●	●	●	F179 F180 F181 F182 F183 F184 F185 F186 F187 F188 F191
(4) 2004	F/T series(North America)	ABS	ABS	●	●	●	●	●	
(4) 2004	F/T series(North America)	Chime module (if equipped)	Chime module (if equipped)	●	●	●	●	○	
(4) 2004	F/T series(North America)	Engine	7.8L Diesel (6HK1)	○	●	●	●	●	F147 F168

Year	Vehicle Type	System Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
(4) 2004	F/T series(North America)	Instrument panel cluster	Instrument panel cluster	●	●	●	●	●	
(4) 2004	F/T series(North America)	Serial data gateway module (if equipped)	Serial data gateway module (if equipped)	●	●	●	○	○	
(4) 2004	C-series(North America)	Engine	7.8L Diesel (6HK1)	○	●	●	●	●	F147 F168
(4) 2004	C-series(North America)	ABS	ABS	●	●	●	●	●	
(4) 2004	C-series(North America)	Chime module (if equipped)	Chime module (if equipped)	●	●	●	●	○	
(4) 2004	C-series(North America)	Instrument panel cluster	Instrument panel cluster	●	●	●	●	●	
(4) 2004	C-series(North America)	Radio	Radio	●	●	●	●	○	
(4) 2004	C-series(North America)	Serial data gateway module (if equipped)	Serial data gateway module (if equipped)	●	●	●	○	○	
(4) 2004	C-series(North America)	Transmission	Transmission	○	●	●	●	●	F179 F180 F181 F182 F183 F184 F185 F186 F187 F188 F191
(4) 2004	(N*) ELF, NPR, NQR, VFR	Engine	4HF1 (CNG)	●	●	●	●	●	
(4) 2004	(C*, E*, L*, F*) Heavy, Medium	Engine	6WF1-TC (C/Rail)	●	●	●	●	●	F38 F65 F68 F70 F117
(3) 2003- (6) 2006	(TF/UC) LUV, Rodeo/Frontier, LAO-Rodeo	Engine	2. XL L4 HV240	●	●	●	●	●	
(3) 2003- (6) 2006	(TF/UC) LUV, Rodeo/Frontier, LAO-Rodeo	Engine	3. 5L V6 6VE1 Hitachi	○	●	●	●	●	
(3) 2003- (6) 2006	(TF/UC) LUV, Rodeo/Frontier, LAO-Rodeo	Transmission	AW30-40LE	●	●	●	●	●	F76 F85
(3) 2003- (6) 2006	(TF/UC) LUV, Rodeo/Frontier, LAO-Rodeo	Chassis	ABS	●	●	●	●	●	
(3) 2003- (6) 2006	(TF/UC) LUV, Rodeo/Frontier, LAO-Rodeo	Body	Airbag	●	●	●	●	○	
(3) 2003- (6) 2006	(N*) ELF, NPR, NQR, VFR	Engine	4JG2	○	●	●	●	●	
(3) 2003- (4) 2004	(C*, E*, L*, F*) Heavy, Medium	Chassis	EBS	●	●	●	●	●	F48
(3) 2003	N/W series(North America)	ABS	ABS	○	●	●	●	●	
(3) 2003	N/W series(North America)	Engine	5. 7L (FED) Gas	○	●	●	●	●	F152 F153 F169 F194
(3) 2003	N/W series(North America)	Transmission	Transmission	○	●	●	●	●	
(3) 2003	N/W series(North America)	Engine	6. 0L Gas	○	●	●	●	●	F152 F153 F154 F155
(3) 2003	N/W series(North America)	Engine	5. 7L (CAL) Gas	○	●	●	●	●	F152 F153 F169 F193
(3) 2003	FRR/WT5500(North America)	Transmission	Transmission	○	●	●	●	●	
(3) 2003	C-series(North America)	Engine	7. 8L Diesel (6HK1)	○	●	●	●	●	F147 F168
(3) 2003	C-series(North America)	ABS	ABS	●	●	●	●	●	
(3) 2003	C-series(North America)	Chime module (if equipped)	Chime module (if equipped)	●	●	●	●	○	
(3) 2003	C-series(North America)	Instrument panel cluster	Instrument panel cluster	●	●	●	●	●	
(3) 2003	C-series(North America)	Radio	Radio	●	●	●	●	○	
(3) 2003	C-series(North America)	Serial data gateway module (if equipped)	Serial data gateway module (if equipped)	●	●	●	○	○	

Year	Vehicle Type	System Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
(3) 2003	C-series(North America)	Transmission	Transmission	○	●	●	●	●	F179 F180 F181 F182 F183 F184 F185 F186 F187 F188 F191
(2) 2002-(6) 2006	(TF/UC) LUV, Rodeo/Frontier, LA0-Rodeo	Engine	4JA1-TC Bosch	●	●	●	●	●	F76 F85
(2) 2002-(6) 2006	(TF/UC) LUV, Rodeo/Frontier, LA0-Rodeo	Engine	4JH1-TC Bosch	●	●	●	●	●	F76 F85
(2) 2002-(6) 2006	(TF/UC) LUV, Rodeo/Frontier, LA0-Rodeo	Transmission	AT JR405E	●	●	●	●	●	F76 F85
(2) 2002-(6) 2006	(TF/UC) LUV, Rodeo/Frontier, LA0-Rodeo	Body	Immobiliser	●	●	●	●	○	F54
(2) 2002-(5) 2005	(C*, E*, L*, F*) Heavy, Medium	Transmission	AT Allison LCT	○	●	●	●	●	
(2) 2002-(4) 2004	(TF/UC) LUV, Rodeo/Frontier, LA0-Rodeo	Engine	4JH1-T Denso	●	●	●	●	●	F76 F85
(2) 2002-(3) 2003	(TF/UC) LUV, Rodeo/Frontier, LA0-Rodeo	Engine	3.2L V6 6VD1 Hitachi	●	●	●	●	●	
(2) 2002-(3) 2003	(TF/UC) LUV, Rodeo/Frontier, LA0-Rodeo	Engine	3.5L V6 6VE1 Hitachi	●	●	●	●	○	
(2) 2002-(3) 2003	(TF/UC) LUV, Rodeo/Frontier, LA0-Rodeo	Body	Airbag	●	●	●	●	○	
(2) 2002-(3) 2003	(TF/UC) LUV, Rodeo/Frontier, LA0-Rodeo	Body	Immobiliser	●	●	●	●	○	
(2) 2002-(3) 2003	(TBR).	Engine	2. XL L4 HV240	●	●	●	●	●	
(2) 2002-(3) 2003	(N*) ELF, NPR, NQR, VFR	Engine	4HL1/4HJ1 (COMMON RAIL)	●	●	●	●	●	F24
(2) 2002-(3) 2003	(N*) ELF, NPR, NQR, VFR	Engine	4HL1/4HJ1 (Vehicle Interface Module)	●	○	○	●	○	
(2) 2002	N/W series(North America)	Engine	5.7L (FED) Gas	○	●	●	●	●	F152 F153 F169 F193
(2) 2002	N/W series(North America)	Transmission	Transmission	○	●	●	●	●	
(2) 2002	N/W series(North America)	ABS	ABS	○	●	●	●	●	
(2) 2002	N/W series(North America)	Engine	5.7L (CAL) Gas	○	●	●	●	●	F152 F153 F169 F193
(2) 2002	FRR/WT5500(North America)	Transmission	Transmission	○	●	●	●	●	
(2) 2002	(TF/UC) LUV, Rodeo/Frontier, LA0-Rodeo	Engine	3.2L V6 6VD1 Hitachi	●	●	●	●	●	
(1) 2001-(6) 2006	(N*) ELF, NPR, NQR, VFR	Engine	4JH1-TC Bosch	●	●	●	●	●	F76 F85
(1) 2001-(6) 2006	(N*) ELF, NPR, NQR, VFR	Engine	4JH1-TC Bosch	●	●	●	●	●	F76 F85
(1) 2001-(2) 2002	TF/UC Thailand	Engine	4JH1-T Denso	●	●	●	●	○	F76 F85
(1) 2001-(2) 2002	TF/UC Thailand	Transmission	AW30-40LE	●	●	●	●	●	
(1) 2001	N/W series(North America)	Engine	5.7L (FED) Gas	○	●	●	●	●	F152 F153 F169 F193
(1) 2001	N/W series(North America)	Transmission	Transmission	○	●	●	●	●	
(1) 2001	N/W series(North America)	ABS	ABS	○	●	●	●	●	
(1) 2001	N/W series(North America)	Engine	5.7L (CAL) Gas	○	●	●	●	●	F152 F153 F169 F193
(1) 2001	(TF) LUV	Engine	4JA1-TC Bosch	●	●	●	●	●	F76 F85

Year	Vehicle Type	System Type	System Name	Ecu Info.	Read Codes	Erase Codes	Live Data	Active Test	Specil Function
(1) 2001	(TF) LUV	Engine	4JH1-TC Bosch	●	●	●	●	●	F76 F85
(1) 2001	(TF) LUV	Body	Immobiliser	●	●	●	●	○	F54
(Y) 2000	N/W series(North America)	Engine	5.7L (CAL) Gas	○	●	●	●	●	F152 F153 F195
(Y) 2000	N/W series(North America)	Transmission	Transmission	○	●	●	●	●	
(Y) 2000	N/W series(North America)	ABS	ABS	○	●	●	●	●	
(Y) 2000	N/W series(North America)	Engine	5.7L (FED) Gas	○	●	●	●	●	F152 F153 F194 F196
(X) 1999-(6) 2006	(N*) ELF, NPR, NQR, VFR	Chassis	ABS/ASR	●	●	●	●	●	
(X) 1999	N/W series(North America)	Engine	5.7L (FED) Gas	○	●	●	●	●	F152 F153 F194 F195
(X) 1999	N/W series(North America)	Transmission	Transmission	○	●	●	●	●	
(X) 1999	N/W series(North America)	ABS	ABS	○	●	●	●	●	
(X) 1999	N/W series(North America)	Engine	5.7L (CAL) Gas	○	●	●	●	●	F152 F153 F194
(W) 1998-(1) 2001	(TF) LUV	Engine	3.2L V6 6VD1 Hitachi	●	●	●	●	●	
(W) 1998	N/W series(North America)	Engine	5.7L (CAL) Gas	○	●	●	●	●	F152 F153 F194
(W) 1998	N/W series(North America)	Transmission	Transmission	○	●	●	●	●	
(W) 1998	N/W series(North America)	Engine	5.7L (FED) Gas	○	●	●	●	●	F152 F153 F194 F195
(V) 1997	N/W series(North America)	Engine	5.7L (CAL) Gas	○	●	●	●	○	
(V) 1997	N/W series(North America)	Transmission	Transmission	○	●	●	●	○	
(V) 1997	N/W series(North America)	Engine	5.7L (FED) Gas	○	●	●	●	●	F152 F153 F195
(T) 1996	N/W series(North America)	Engine	5.7L (CAL) Gas	○	●	●	●	○	
(T) 1996	N/W series(North America)	Transmission	Transmission	○	●	●	●	○	
(T) 1996	N/W series(North America)	Engine	5.7L (FED) Gas	○	●	●	●	●	F152 F153 F195

Special_Function

Index	Special Function Name	Index	Special Function Name
F1	Accumulated ENG Log Data Clearing	F2	Accumulated ENG Runtime Resetting
F3	Accumulated T/M Log Data Clearing	F4	Adjustment Radar Vertical Axis
F5	Adjustment Radar learning Date	F6	Alarm of EG Oilife distance Clear
F7	Alarm of Engine Oil life Mileag	F8	Alarm of TM Oil life Mileage
F9	Alarm of TM Oilife distance Clear	F10	All Accumulation Data Clearing
F11	All Data	F12	All Data (ECM & ECU)
F13	CMS(Collision Mitigation Brake)	F14	Calibration Data
F15	Clear Adaptives to Fast+Base	F16	Clear Clutch Learned Values
F17	Clear DMU Data	F18	Clear DPD Data
F19	Clear Drive Recorder Data	F20	Clear Gear Learned Values
F21	Clear Injection Learned Value	F22	Clear Load History
F23	Clear MIMAMORI Data	F24	Clear Pump Adjustment Learned
F25	DPD Automatic Regeneration	F26	DPD Normal Regeneration Control
F27	DPD Regeneration Control	F28	DPD Regeneration Control 1
F29	DPD Regeneration Control 2	F30	DPD Slow Regeneration Control
F31	DPD Slow Regeneration Control 1	F32	DPD Slow Regeneration Control 2
F33	DPD Slow Regeneration Control	F34	DPD Status Resetting
F35	DTC Data Except ECM	F36	Display Injector Codes
F37	Display Injector Quantity Trim	F38	Download ID Code
F39	ECM (Engine Control Module)	F40	ECM DTC Data
F41	ECU Lock	F42	EGR Valve Zero Position Learn
F43	ENG Log Data Force Recording	F44	ENG Oil Additional Distance
F45	ENG Oil Distance Resetting	F46	ENG Oil Preset Interval
F47	ENGINE DMU ALL DATA CLEAR	F48	EOL Parameter
F49	ESC(Electronic Stability Control)	F50	Engine (C/Rail)
F51	Engine Oil Alarm Value	F52	Engine Oil Exchange Reset
F53	Engine Type Programming	F54	Erase Transponder-Keys
F55	FORCED ENGINE DMU RECORD	F56	FORCED Hybrid DMU RECORD
F57	FORCED TCM DMU RECORD	F58	Final Gear Ratio Programming
F59	Forced DMU Data Record	F60	Fuel Consumption Data Resetting
F61	Fuel Data Display Clear	F62	Fuel Delivery Rate Data
F63	Fuel Supply Pump Learn Resetting	F64	Fuel Trim Reset
F65	History Information	F66	Hour Meter Information Clear
F67	Hybrid DMU ALL DATA CLEAR	F68	ID Code Registration
F69	Idle Air Control	F70	Injector ID Code
F71	Injector Programming	F72	Injector Quantity Trim
F73	Input/Output	F74	Lateral Acceleration Parameter
F75	Life Reset Request	F76	Lock ECU
F77	MIMAMORI ALL DATA CLEAR	F78	MIMAMORI ALL DTC REC CLEAR
F79	Main Function	F80	Offset Steering Angle
F81	PTO Requested Engine Speed	F82	Prog. ECU Locking Function
F83	Program Tire Compensation	F84	Program Tire Size
F85	Program VIN	F86	Program Vehicle Identification No.
F87	Program Vehicle Type	F88	Programming Engine Type
F89	RKE REGISTRATION	F90	RKE Registration Clear
F91	Radar Learning Flag	F92	Radar Learning Request
F93	Reset Autodetect Information	F94	Reset DPD Regenerate
F95	Reset DPD Regenerate 1	F96	Reset DPD Regenerate 2
F97	Reset Fuel Pump Correction	F98	Reset O2-Loop Block Learn Map
F99	Reset Oil Life Monitor	F100	Reset TAP Cells
F101	Starter duration of life Counts	F102	T/M Log Data Force Recording
F103	T/M Oil Additional Distance	F104	T/M Oil Distance Resetting
F105	T/M Oil Preset Interval	F106	TCM DMU ALL DATA CLEAR

Index	Special Function Name	Index	Special Function Name
F107	Throttle Body Relearn	F108	Tire Size Programming
F109	Tooth Error Correction	F110	Transmission Oil Alarm Value
F111	Transmission Type Programming	F112	Update AD Input
F113	Update Engine Type	F114	Update Information Onboard ECU
F115	Update Transmission Type	F116	Update Vehicle Configuration
F117	Upload ID Code	F118	VIN Programming
F119	Vehicle Identification	F120	Engine oil life options english I/P
F121	Engine oil life options metric I/P	F122	Fuel economy meter reset
F123	Hour meter reset	F124	Engine log data clear
F125	A/T log data clear	F126	SCR system log data clear
F127	A/T event data clear	F128	DEF injector control
F129	DEF injector data reset	F130	EGT sensor 3 data reset
F131	NOx sensor 1 data reset	F132	NOx sensor 2 data reset
F133	DEF control module data reset	F134	SCR catalyst data reset
F135	Oxidation catalyst data reset	F136	DPF normal regeneration
F137	DPF slow regeneration	F138	Exhaust differential pressure sensor learn
F139	Clear DPF data	F140	Clear ECM learned data
F141	Idle shutdown extension	F142	Vehicle speed limit
F143	Cruise control	F144	Exhaust brake
F145	PTO options	F146	Idle shutdown
F147	Injector flow rates	F148	Speedometer calibration
F149	Module Setup	F150	Idle spark
F151	Spark retard	F152	Fuel trim enable
F153	Fuel trim reset	F154	Engine speed control
F155	CKP variation learn	F156	H02S heater learn
F157	PIM security password - quick learn	F158	Program Engine Serial number
F159	Reset transmission adapts	F160	Supply pump learn reset
F161	Engine shutdown/warning protection	F162	Base engine idle speed
F163	DPF options	F164	All parameters(not editable)
F165	Stationary preset PTO	F166	Stationary variable PTO
F167	Mobile variable PTO	F168	Injector trim
F169	RPM control	F170	DPF normal regen
F171	DPF slow regen	F172	Engine shutdown
F173	Engine idle shutdown	F174	Engine oil
F175	Engine idle speed	F176	Gear down protection
F177	Wayne engineering PTO only	F178	High idle switch option PTO
F179	Clear all TAP cells	F180	Clear all garage shift TAP
F181	Clear 1-2 TAP	F182	Clear 2-1 TAP
F183	Clear 2-3 TAP	F184	Clear 3-2 TAP
F185	Clear 3-4 TAP	F186	Clear 4-3 TAP
F187	Clear 4-5 TAP	F188	Clear 5-4 TAP
F189	Clear 5-6 TAP	F190	Clear 6-5 TAP
F191	Preset all TAP cells	F192	Idle learn reset
F193	Crankshaft position (CKP) variation learn	F194	Crankshaft variation learn
F195	IAC reset		