

MaxiSysCV_OBD_V2.00 Function List

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 - This function is not supported. ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.**

| Function | Mode | ISO 15765-4 (CAN) | SAE J1939 (CAN) | SAE J1587/1708 | SAE J1850 (PWM) | SAE J1850 (VPW) | ISO 14230-4 (KWP2000) | ISO 9141-2 |
|-------------------|------------------------|----------------------|--------------------|----------------|--------------------|--------------------|--------------------------|------------|
| DTC&FFD | \$02, \$03, \$04, \$07 | ● | ● | ● | ● | ● | ● | ● |
| DTC&FFD | \$0a | ● | ○ | ○ | ○ | ○ | ○ | ○ |
| Live Data | \$01 | ● | ● | ● | ● | ● | ● | ● |
| Vehicle Status | \$01 | ● | ● | ● | ● | ● | ● | ● |
| I/M Readiness | \$01 | ● | ● | ○ | ● | ● | ● | ● |
| O2 Sensor Monitor | \$05 | ○ | ○ | ○ | ● | ● | ● | ● |
| On-Board Monitor | \$06 | ● | ○ | ○ | ● | ● | ● | ● |
| Component Test | \$08 | ● | ○ | ○ | ● | ● | ● | ● |
| Vehicle Info. | \$09 | ● | ● | ● | ● | ● | ● | ● |