Autel®

MaxiSYS_Eaton_V1.00 Function List (Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported,which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

As for special function please refer to the special function table.

System	Subsystem	Info.	Read codes	Clear codes	Freeze frame	Live data	Active test	Spec function
GEN1		●	●	●	○	●	○	○
GEN2		●	●	●	○	●	○	○
GEN3	J1939	●	●	●	○	●	○	○
GEN3	J1708	●	●	●	○	●	○	○
LIGHTNING		●	●	●	○	●	○	○
HYBRID	J1939	●	●	●	○	●	○	○
HYBRID	J1708	●	●	●	○	●	○	○
EPS	J1939	●	●	●	○	●	○	○
EPS	J1708	●	●	●	○	●	○	○
ARBETER	J1939	●	●	●	○	●	○	○
ARBETER	J1708	●	●	●	○	●	○	○
HDHYBRID	J1939	●	●	●	○	●	○	○
HDHYBRID	J1708	●	●	●	○	●	○	○
HCM	J1939	●	●	●	○	●	○	○
HCM	J1708	●	●	●	○	●	○	○
HDHCM	J1939	●	●	●	○	●	○	○
HDHCM	J1708	●	●	●	○	●	○	○
EVT300		●	●	●	○	●	○	○
VS400DIU		●	●	●	○	●	○	○
VS400FLR		●	●	●	○	●	○	○