ERF

1. X : means the function is supported.
2. * : means the function is added or developed newly in the new version

VEHICLE INFORMATION		FUNCTION					
Module	System	ECU INFO	DTC	DTC Freeze	Data List	Actuations	Spec. Func.
ECT	Engine	X	X		X		
ECT	Engine	X	X		X		
ECT	Engine	X	X		X		
ECT	Engine	X	X		X		
ECT	Engine	X	X		X		
ECT	Engine	X	X		X		
ECT	Engine-Vehicle Adjustment	X	X		X		
ECT	Instrumentation	X	X		X		
ECT	Heating/air-condition	X	X		X		
ECT	Heating/air-condition	X	X		X		
ECT	Heating/air-condition	X	X		X		
ECT	Heating/air-condition	X	X		X		
ECT	Heating/air-condition	X	X		X		
ECT	EBS	X	X		X		
ECT	EBS	X	X		X		
ECT	EBS	X	X		X		
ECT	EBS	X	X		X		
ECT	EBS	X	X		X		
ECT	EBS	X	X		X		
ECT	EBS	X	X		X		